



EMESENT AURA USER MANUAL

DOCUMENT NUMBER: UM-020
REVISION NUMBER: 3.5
RELEASE DATE: 03 DEC 2025

PREPARED BY:
EMESENT PTY LTD
LEVEL G, BUILDING 4, KINGS ROW OFFICE PARK
40-52 MCDUGALL ST, MILTON, QLD, 4064 AUSTRALIA

EMAIL: CLIENT.SUCCESS@EMESENT.COM
PHONE: +61 7 3548 9494



Copyright

The content of this document is confidential and intended for reading only by the addressee. All rights including Intellectual Property Rights flowing from, incidental to or contained in this document irrevocably vest in Emesent unless otherwise agreed to in writing.

©Emesent 2024

Using this manual

Hovermap is a powerful system that can be used as a LiDAR mapping payload, but also as an advanced autopilot for drones and other platforms. We therefore recommended that you read the user manual thoroughly to make use of all its capabilities in a safe and productive way.

Disclaimer and safety guidelines

This product is *not* a toy and must not be used by any person under the age of 18. It must be operated with caution, common sense, and in accordance with the instructions in the user manual. Failure to operate it in a safe and responsible manner could result in product loss or injury.

By using this product, you hereby agree that you are solely responsible for your own conduct while using it, and for any consequences thereof. You also agree to use this product only for purposes that are in accordance with all applicable laws, rules and regulations.

The use of Remotely Piloted Aircraft Systems (RPAS) may result in serious injury, death, or property damage if operated without proper training and due care. Before using an RPAS, you must ensure that you are suitably qualified, have received all necessary training, and read all relevant instructions, including the user manual. When using an RPAS, you must adopt safe practices and procedures at all times.



Warnings

- This document is legally privileged, confidential under applicable law and is intended only for the use of the individual or entity to whom it is addressed. If you have received this transmission in error, you are hereby notified that any use, dissemination, distribution or reproduction is strictly prohibited. If you are not the intended recipient, please notify the sender and delete the message from your system.
- Do not attempt to disassemble, repair, tamper with, or modify the this product. This product contains no user-serviceable parts inside. Any disassembly of the product enclosure will invalidate the IP65 rating and disrupt the factory calibration of LiDAR. Contact Emesent for any repairs or modifications.
- Always be aware of moving objects that may cause serious injury, such as spinning propellers or other components. *Never* approach a drone while the propellers are spinning or attempt to catch an airborne drone.





Contents

- 1. System Requirements 1**
- 1.1 Processor 1
- 1.2 Memory 1
- 1.3 Storage 1
- 1.4 Graphics Card 1
- 1.5 Operating System 1
- 2. Quick Start: Accessing Aura 1**
- 2.1 Step 1: Verify license availability 1
- 2.2 Step 2: Activate your Emesent account 1
- 2.3 Step 3: Install Aura software 1
- 2.4 Step 4: Sign in to Aura 1
- 2.5 Step 5: Begin data processing 1
- 2.6 Troubleshooting 1
- 2.7 Want to Know more? 1
- 3. Licensing & User Management 1**
- 3.1 Legacy Licensing (Aura 1.10.2 and earlier) 1
- 3.2 Concurrent User Licencing 1
- 3.2.1 Licencing in Aura (CUL) 1
- 3.2.1.1 Purpose and Function 1
- 3.2.1.2 How Licensing Works in Aura 1
- 3.2.1.3 Requirements 1
- 3.2.1.4 Related Information 1
- 3.2.2 How to request access 1
- 3.2.3 How to log into Aura 1
- 3.2.4 How to check license details 1
- 3.2.5 How to check in a license 1



- 3.2.6 How to check out a license..... 12
- 3.2.6.1 Check out a license..... 12
- 3.2.7 Aura Licencing FAQ 1
- 3.2.7.1 Core Concepts 1
- 3.2.7.2 Licensing Model..... 1
- 3.2.7.3 Using Seats in Aura 1
- 3.2.7.4 Requirements and Compatibility..... 1
- 3.2.7.5 Troubleshooting 1
- 3.3 Emesent User Management 1
- 3.3.1 How to access the Emesent User Management 1
- 3.3.2 How to invite a new user 23
- 3.3.3 How to resend or revoke an Invitation 1
- 3.3.4 How to change a users role 1
- 3.3.5 How to remove a user 1
- 4. Emesent Aura User Interface 1**
- 4.1 User Profile menu 1
- 4.1.1 Log in and Log out 1
- 4.1.2 Licence Details 1
- 4.1.3 User Management..... 1
- 4.2 Context Panel 1
- 4.2.1 Point Clouds..... 1
- 4.2.1.1 Point Cloud Visualization..... 1
- 4.2.1.2 Point cloud properties..... 1
- 4.2.2 Ground Control Points 1
- 4.2.2.1 Edit Constellation 1
- 4.2.2.2 Inactive Landmarks 1
- 4.2.2.3 Inactive Targets 1
- 4.3 Process Tab 1
- 4.3.1 Configure New Scan Job Panel 1



4.3.2	Processing Queue	1
4.3.2.1	Processing	1
4.3.2.2	Completed	1
4.3.2.3	Failed.....	1
4.3.3	Processing Settings	1
4.3.3.1	General Tab.....	1
4.3.3.2	GCP Tab.....	1
4.3.3.3	Merge Tab	1
4.3.3.4	Colorize Tab.....	1
4.3.3.5	Extract 360 Images Tab.....	1
4.3.3.6	Output Tab	1
4.4	Global Settings	1
4.4.1	Project Menu	1
4.4.2	Preferences	1
4.4.3	Capture Screenshot	1
4.5	Viewport.....	1
4.6	Main Toolbar	1
4.7	Visualize Tab	1
4.7.1	Supported File Types.....	1
4.7.2	Moving the Panel.....	1
5.	Working with Point Clouds	1
5.1	Processing Profiles	1
5.1.1	Built-in Profiles.....	1
5.1.2	Custom Profiles.....	1
5.2	Output Folders	1
5.3	Cleaning your Point Cloud	1
5.3.1	Step 1: Copy your point cloud file	1
5.3.2	Step 2: Open in Emesent Aura	1
5.3.3	Step 3: Make your point cloud visible.....	1



- 5.3.4 Step 4: Start with a small area 1
- 5.3.5 Step 5: Use the SOR filter..... 1
- 5.3.6 Step 6: Do a manual clean-up..... 1
- 5.3.7 Step 7: Save 1
- 5.4 Process Workflow..... 1
- 5.4.1 Step 1: Retrieve your scan data 1
- 5.4.2 Step 2: Copy the data to your computer 96
- 5.4.3 Step 3: Configure your processing job 96
- 5.4.4 Step 4: (Optional) Use RTK Data 1
- 5.4.5 Step 5: Processing 1
- 5.4.6 Step 6: View your point cloud 1
- 5.5 GCP Workflow..... 1
- 5.5.1 Processing Scan Data with Ground Control Points (GCPs) 1
- 5.5.1.1 Aura Supports:..... 1
- 5.5.1.2 Requirements 1
- 5.5.1.3 Procedure 1
- 5.5.2 Check Points..... 1
- 5.5.2.1 What are Check Points?..... 1
- 5.5.2.2 How Check Points work in Aura 1
- 5.5.2.3 Using Check Points helps you: 1
- 5.5.2.4 How Check Points are used 1
- 5.5.2.5 Accuracy reporting with Check Points 1
- 5.5.2.6 FAQ 1
- 5.6 Merge Workflow 1
- 5.6.1 Prepare for the Merge..... 1
- 5.6.1.1 Ensure Overlap 1
- 5.6.1.2 Consider System Resources..... 1
- 5.6.1.3 Scan Requirements for Merging 1
- 5.6.2 Merging Scan Data..... 1
- 5.6.2.1 Step 1. Configure Your Merge Job..... 1



- 5.6.2.2 Step 2: Choose an Alignment Base for Preview 1
- 5.6.2.3 Step 3: Configure Apply Overrides (Optional) 1
- 5.6.2.4 Step 4: Select a Reference Scan (Optional)..... 1
- 5.6.2.5 Step 5: Configure Processing Settings 1
- 5.6.2.6 Step 6: Proceed to Alignment 1
- 5.6.2.7 Step 7. Review and Manually Align (If Required) 1
- 5.6.2.8 Step 9. View and Combine Your Datasets 1
- 5.6.2.9 (RTK Only) View the Combined Accuracy Report 1
- 5.6.2.10 Colorize and/or Extract 360 images (Optional)..... 1
- 5.7 Colorization Workflow 1
 - 5.7.1 Before Starting 1
 - 5.7.2 How do I colorize a Point Cloud? 1
 - 5.7.2.1 Step 1: Add scan data & Video 1
 - 5.7.2.2 Step 2: Configure Colorization scan job 1
 - 5.7.2.3 Step 3: Start processing 1
 - 5.7.2.4 Step 4: View your final output 1
 - 5.7.3 How do I colorize a Merged Point Cloud? 1
- 5.8 Extract 360 Images Workflow 1
- 5.9 Moving Object Filtering 156
 - 5.9.1 Using the Moving Object Filter 156
 - 5.9.2 Applying Motion Filtering from Processing Settings 1
- 5.10 Surface Noise Reduction 1
 - 5.10.1 What is Surface Noise Reduction? 1
 - 5.10.2 How to apply Surface Noise Reduction..... 1
 - 5.10.2.1 Option 1: Apply during processing 1
 - 5.10.2.2 Option 2: Apply after processing 1
- 5.11 Creating a Custom Mask..... 1
- 5.12 Reprojection 1
 - 5.12.1 Configure a scan for reprojection 1
 - 5.12.1.1 Step 1: Create a New Processing Job..... 1



- 5.12.1.2 Step 2: Configure Output Location 1
- 5.12.1.3 Step 3: Set Georeferencing Options 1
- 5.12.1.4 Step 4: Define the Base CRS..... 1
- 5.12.1.5 Step 5: Enable and Configure Reprojection 1
- 5.12.1.6 Step 6: Finalise Settings and Start Processing 1
- 5.12.2 Reprojecting a processed point cloud 1
- 5.12.2.1 Step 1: Open Aura Export Reprojection..... 1
- 5.12.2.2 Step 2: Review or Edit the Source CRS 1
- 5.12.2.3 Step 3: Select the Target CRS 1
- 5.12.2.4 Step 4: Apply Optional Reprojection Settings..... 1
- 5.12.2.5 Step 5: Export the Reprojected Point Cloud 1
- 5.13 Measure Tools 1
- 5.13.1 Measurement Tools 1
- 5.13.2 Managing Measurements..... 1
- 5.13.3 Measurement Details..... 1
- 5.13.4 Renaming Measurements 1
- 5.13.5 Export Points..... 1
- 5.14 Aura scan environments 1
- 5.14.1 How Aura uses Scan Environments 1
- 5.14.2 Default Processing Behaviour by Environment 1
- 6. Glossary..... 1**
- 6.1 General Terms 1
- 6.2 Aura Modules..... 200
- 7. Support 201**
- 7.1 Chat with Emi 201
- 7.2 Knowledge Base..... 201
- 7.3 Emesent Academy 201
- 7.4 Submit a Support Request..... 201



1. System Requirements

Your computer must meet the following minimum specifications to run Emesent Aura. For best performance, Emesent recommends using the higher specification where provided.

1.1 Processor

- **Minimum:** 10th Generation Intel Core i9
- **Recommended:** 12th Generation Intel Core i9

1.2 Memory

- **Minimum:** 64 GB DDR4 3200 MHz
- **Recommended:** 128 GB DDR5 4800 MT/s

1.3 Storage

- **Minimum:** 512 GB Samsung 980 Pro NVMe SSD
- **Recommended:** 2 TB Samsung 990 Pro NVMe SSD
- **External storage:** High-speed USB 3.1 drive with at least 128 GB free space for transferring scans from Hovermap to your computer



Do not process scans directly from removable storage or network locations as this can cause significant performance issues. For reliable processing and stable performance, always download scans to your computer's primary SSD before starting a processing job.



1.4 Graphics Card

- **Minimum:** NVIDIA RTX 3070 with 8 GB VRAM
- **Recommended:** NVIDIA RTX 4070 Ti with 12 GB VRAM

1.5 Operating System

- Windows 10 64-bit (x86)
- Windows 11 64-bit (x86) (Recommended)



2. Quick Start: Accessing Aura

Follow these steps to get set up and start using Aura with Concurrent User Licensing.

2.1 Step 1: Verify license availability

Aura 2.0 and later uses Concurrent User Licensing.

- Confirm your organization has an active Aura license.
- Ask your project lead or Emesent license administrator if you are unsure.
- [Learn more about Aura Concurrent User Licensing](#)

2.2 Step 2: Activate your Emesent account

You need an Emesent account linked to your organization's license.

- Your organization's Emesent license administrator will invite you by email through [Emesent User Management](#).
- Accept the invitation and set your password.
- If you do not know who your administrator is, complete the [Transition Contact Form](#) and a member of Emesent will contact you.

2.3 Step 3: Install Aura software

Ensure your computer meets the [system requirements](#) for Aura.

- Install Aura 2.0 or later.
- Installation files are available:
 - From the **Welcome to Emesent** page in the [User Management](#) after login
 - From the [Emesent Software Downloads page](#)
 - Through your organization's software distribution system, if applicable



2.4 Step 4: Sign in to Aura

- Open Aura and click the **User Profile** menu in the top right corner.
- Select **Log In** and enter the Emesent account credentials you set up in Step 2.
- For detailed guidance, see [How to Log In to Aura](#).

2.5 Step 5: Begin data processing

- Once logged in, Aura automatically checks out a seat from your organization's license pool when you start processing.
- If you need to work offline, see [How to Check Out a License for Offline Use](#).
- To confirm your entitlements at any time, see [How to Check Your License Information](#).

2.6 Troubleshooting

- Can't log in? See [How to Request Access to Aura](#).
- Emesent license administrators: See [User Management Portal Guide](#) to invite and manage users.

2.7 Want to Know more?

- [Licensing in Aura](#)
- [Emesent Aura Release Notes](#)

3. Licensing & User Management

Aura uses a **concurrent user licensing model**, allowing organisations to share a pool of processing seats across multiple users, devices, and work locations. This model ensures licences are used efficiently, providing access when and where it is needed without tying seats to specific machines.


User access and permissions are managed through **Emesent User Management**. Administrators can invite new users, update roles, adjust permissions, or remove access at any time. This centralised approach



ensures your organisation maintains full oversight of who can sign in and use Aura's processing capabilities.

To process data in Aura, you must sign in with your Emesent account. After logging in, Aura checks your organisation's licence pool and assigns a seat automatically if one is available. If no seat is free, Aura will still open normally, but processing features will remain disabled until a licence becomes available.

You can view your current licence status at any time by selecting **Licence** in the top-right corner of Aura. This panel displays whether you have an active seat, its expiry details, and whether it is currently checked out for offline use. Aura also provides notifications when your licence is nearing expiry or if your offline period is reaching its limit.

 Aura monitors licence usage throughout your session. If you check out a licence for offline work, make sure you return it when you no longer need it. This helps keep seats available for other users within your organisation.

3.1 Legacy Licensing (Aura 1.10.2 and earlier)

In Aura versions 1.10.2 and earlier, licences were managed via a **physical USB dongle**. The dongle had to remain connected while using Aura to maintain access to processing features. While dongle-based licensing is still supported for older versions, it is no longer used in Aura 2.0 and above.



3.2 Concurrent User Licencing

3.2.1 Licencing in Aura (CUL)

Aura 2.0 and later use a **Concurrent User Licencing** (CUL) system. This replaces physical hardware dongles with user account-based access, allowing organizations' to centrally manage entitlements and share processing seats across machines and locations.

License access is managed through the **Emesent User Management Portal**, providing a simple way to assign and control access. Within Aura, licenses are automatically checked out when processing begins, or they can be checked out manually for a set duration to enable offline use.

3.2.1.1 Purpose and Function

A license in Aura grants the right to process data. Licenses are allocated as **processing seats**, which can be shared across your organization:

- Each seat can be assigned to up to **10 active users**.
- Each seat lets **one user process at a time**, ensuring clear access without conflicts.
- Organizations with multiple seats can register additional users and increase simultaneous processing capacity.
- Each license includes one or more **modules**, which enable specific processing functions within Aura.

3.2.1.2 How Licencing Works in Aura

Automatic checkout and return

- When a user begins processing in Aura, a seat is automatically checked out if one is available.
- Once processing ends, the seat is automatically returned to the shared pool (if an internet connection is available).

Manual checkout for offline use

- Users can manually check out a seat for between 1 and 14 days, enabling offline processing without an internet connection.



- These seats are only returned manually by the user, or automatically when the checkout period expires.

i All data processing is performed locally on the user's machine. Internet access is only required for login and for checking out a processing seat.

3.2.1.3 Requirements

To use Concurrent User Licensing in Aura:

Requirement	Description
Software	Aura version 2.0 or later must be installed.
License	An active Emesent license is required (excluding Hovermap 100 systems).
Connectivity	An internet connection is required for login and checking out a processing seat. Seats can be manually checked out for offline use but must be checked out while connected to the internet.

3.2.1.4 Related Information

- See the **Aura Licensing FAQ** for detailed questions and answers.
- Refer to the **Aura Licensing section on the Knowledge Base** for step-by-step instructions on logging in, checking out seats, and managing offline use.
- Contact your **Emesent Sales representative, reseller, or account manager** for further assistance.

3.2.2 How to request access

If you are unable to log in or Aura does not assign a license automatically, you may need to request access.

Option 1: Contact your internal license administrator

Reach out to your organisation's designated license manager. They can grant access through the Emesent Licensing Portal.




Option 2: Contact Emesent Client Support

Complete the [Transition Contact form](#)

3.2.3 How to log into Aura

To use Aura with a concurrent license, you must log in with your Emesent account. This account is linked to your organization's shared licensing pool.

1. Open Aura from your desktop or start menu.
2. Click the **User Profile** icon in the top-right corner.



3. Click **Login**. Aura opens your default web browser and displays the secure login page.
4. Enter your Emesent account email and click **Continue**.
5. Enter your password and click **Continue** to complete the login.



When you start processing, Aura automatically checks for available seats. If a license is available, it is allocated to your processing job.

If you do not have an Emesent account, contact your organisation's Emesent account administrator. If an administrator is not available, complete the [Transition Contact form](#).

3.2.4 How to check license details

You can view details about your current license, including active modules, license ID, and expiry dates.

1. Open Aura.
2. Click the **User Profile** icon in the top-right corner.
3. Click **License Details**.



The License Details panel shows:

- License ID
- Modules assigned (e.g. SLAM, RTK, GCP)
- Expiry date for each module




- Checkout status (if the license is currently checked out)



3.2.5 How to check in a license

A license can be checked back into the shared pool at any time when an internet connection is available. To check in a license, follow these steps:

1. Open the **License Details** menu from one of the following locations:
 - The **User Profile** menu by clicking the **User Profile** icon and selecting **License Details**.
 - The **Process** tab by clicking **Return Seat** on the right-hand side.



2. Locate the checked-out license and select **Return Seat**.



LICENSE DETAILS

Aura Processing Seats

Company: Example Co

ID	Modules	Valid until	
85185045752366386	SLAM, GCP, Colorization, Convergence monitoring & RTK	Perpetual	CHECKED OUT RETURN SEAT Time remaining: 00:23:59:21
802667481255720140	SLAM	Perpetual	
524893813066775785	SLAM, GCP, RTK & Convergence monitoring	Perpetual	

[REQUEST LICENSE UPGRADE](#)

- 4. Click **Confirm** to return the license early and free it for other users.

RETURN PROCESSING SEAT

ID: 85185045752366386; SLAM, GCP, Colorization, Convergence monitoring & RTK

Are you sure you want to return this processing seat?

You will be able to return the seat when connected to the internet, otherwise it will automatically return once the time expires. You can process datasets when connected to the internet and if there are seats available.

CANCEL CONFIRM

Checked-in licenses become immediately available for other users.



3.2.6 How to check out a license

3.2.6.1 Check out a license

By default, Aura **handles license check-out and check-in automatically** during processing.


If you'll be working **without internet access**, you can instead **manually check out a license** for offline use.

Checking out a license reserves it for offline use, removing it from the shared pool until it is manually **checked in** or the checkout period expires.

To check out a license, follow these steps:

Step 1: Open the License Details

1. Open **Emesent Aura**.
2. Go to the **User Profile menu** in the top-right corner.
3. Select **License Details** to open the License Details menu.



Step 2: Select a License

1. In the **License Details table**, review all available licenses, their **modules**, and their **expiry dates**.
2. Find a license that **meets your requirements**.
3. Click the blue **Check Out** button on the right-hand side.



- a. This opens the **Offline Processing menu**.

The screenshot shows a dark-themed window titled "LICENSE DETAILS" with a close button (X) in the top right corner. Below the title is the section "Aura Processing Seats" and the text "Company: Example Co" with a refresh icon (C) on the right. A table lists three license seats with columns for ID, Modules, Valid until, and a "CHECK OUT" button. The first row has ID 85185045752366386, Modules "SLAM, GCP, Colorization, Convergence monitoring & RTK", and Valid until "Perpetual". The second row has ID 802667481255720140, Modules "SLAM", and Valid until "Perpetual". The third row has ID 524893813066775785, Modules "SLAM, GCP, RTK & Convergence monitoring", and Valid until "Perpetual". A "REQUEST LICENSE UPGRADE" link is at the bottom left.

ID	Modules	Valid until	
85185045752366386	SLAM, GCP, Colorization, Convergence monitoring & RTK	Perpetual	CHECK OUT
802667481255720140	SLAM	Perpetual	CHECK OUT
524893813066775785	SLAM, GCP, RTK & Convergence monitoring	Perpetual	CHECK OUT

[REQUEST LICENSE UPGRADE](#)

Step 3: Define Offline Use

1. In the **Offline Processing menu**, review the selected **seat**, assigned **modules**, and the **expiry date**.
2. In the **bottom-left corner**, use the **drop-down menu** to select the number of **days** required for offline use.
3. When ready, click **Confirm** to complete the license check-out.



✕

OFFLINE PROCESSING

Check out seat for offline use:

ID	Modules	Valid until
85185045752366386	SLAM, GCP, Colorization, Convergence monitoring, RTK	Perpetual

Check out processing seat for:

Days: 1 ^

1

2

3

4

5

6

7

The processing time window is 1 day. The license will be checked back in when the time expires and the last processing job is completed within the time window.

BACKCONFIRMCANCEL

i **Once a license is checked out for offline use:**

- The license is **locked to your machine** for the defined period.
- **Other users cannot access** the license until it is checked in or expires.
- You can continue using Aura **offline without an internet connection.**

Remember to **check in the license** when no longer needed to avoid blocking others.

Step 4: Check in a license

If you need to **check in your license early**, refer to the [How to Check In a License](#) article for detailed instructions.



3.2.7 Aura Licencing FAQ

3.2.7.1 Core Concepts

What is a license?

A license grants permission to use Aura’s processing features. Each license includes one or more modules, which enable specific functionality such as SLAM processing or RTK corrections.

What is a module?

Modules are specific functional components within Aura. Licenses may include access to one or more of the following modules:

Module	Description
SLAM	Enables SLAM (Simultaneous Localization and Mapping) processing.
RTK	Allows integration of RTK GNSS data for improved georeferencing.
GCP	Enables georeferencing using Ground Control Points.
Colorize	Adds colour information to point clouds using captured imagery.
Convergence Monitoring	Allows visualization of changes between two scans of the same tunnel area.

What is a processing seat?

A seat is a unit of access to Aura’s processing capabilities. Seats can be assigned to multiple users within an organization, with one user processing at a time.



3.2.7.2 Licensing Model

What is Concurrent User Licensing?

Concurrent User Licensing (CUL) is the model used in Aura 2.0 and later. It replaces hardware dongles with account-based access. Organizations are allocated a pool of processing seats, which can be shared across machines and locations.

What are the benefits of Concurrent User Licensing?

- **Greater flexibility** – process data on any compatible machine, from any location.
- **Faster deployment** – start processing immediately once logged in.
- **Reduced downtime** – no risk of lost or damaged dongles.
- **Streamlined management** – license changes are applied automatically, with no file exchanges required.

3.2.7.3 Using Seats in Aura

How are processing seats managed?

- Organizations receive seats based on their license entitlements.
- Each seat can be shared by up to **10 active users**, with one user able to process at a time.
- If all seats are in use, additional users must wait until one becomes available.

Example:

- 2 seats → up to 20 registered users, 2 users processing at the same time.
- 1 seat → up to 10 registered users, 1 user processing at a time.

How do users log in to Aura?

Each user logs in with a unique email and password. Seats are automatically checked out when processing begins and returned when processing ends.



Can Aura be used offline?

Yes. A seat can be manually checked out for **1 to 14 days** to enable offline processing. Processing is always performed locally; internet access is only required for login and seat management.

3.2.7.4 Requirements and Compatibility

What is required to use Concurrent User Licensing?

- Aura **2.0 or later**
- An **active Emesent License** (excluding Hovermap 100 systems)
- **Internet access** for login and license management

Which Hovermaps support Concurrent User Licensing?

- **Supported:** Hovermap ST and ST-X
- **Not supported:** Hovermap 100

Can hardware dongles still be used with Aura?

With the release of Aura 2.0, licensing has moved to Concurrent User Licensing. Hardware dongles are **not supported in Aura 2.0 or later**.

However, if you are running an earlier version of Aura (latest pre-2.0 release: 1.10.2), your dongle will continue to function until its expiry date.

3.2.7.5 Troubleshooting

Why can't I log in to Aura?

Cause:

- Incorrect email or password.
- No active internet connection.



- User account not yet registered in the Emesent User Management Portal.

Solution:

- **Re-enter** your email and password carefully.
- **Ensure** you have an active internet connection.
- **Confirm** with your organization's Emesent administrator that your account is registered in your company's system.
- **Contact** Emesent using the [transition contact](#) form if you cannot locate your local administrator.

Why am I unable to process even though I am logged in?

Cause:

- All available seats are already in use.
- Organization may not have enough seats to support current demand.

Solution:

- Check the number of available seats in Aura under **License Details** in the **User Profile** menu.
- Wait until a seat becomes available.
- If capacity issues continue, ask your **administrator** to review whether additional seats are required.

Why can't I process offline?

Cause:

- A seat was not manually checked out before going offline.
- The manual checkout period has expired.

Solution:

- Connect to the internet and **manually check out a seat** before going offline.
- Seats can be checked out for **1-14 days**. If the period has expired, reconnect to the internet to renew.
- See the step-by-step guide on **checking out a license** [here](#).



Reference

What do key terms mean?

Term	Definition
Concurrent User Licensing (CUL)	Licensing model that replaces dongles with account-based access.
Processing seat	A license allocation that allows one user to process at a time, shareable by up to 10 or more registered users depending on your agreement with Emesent.
License	The right to process data in Aura, managed through user accounts.
Hardware dongle	A USB device previously required to use Aura, no longer supported in Aura 2.0 and later.
Module	A functional component included in a license that enables specific processing features (e.g., SLAM, RTK, GCP, Merge, Colorize).
Manual checkout	The process of checking out a seat for offline use for a set duration (1-14 days).
Emesent User Management Portal	The web portal used to assign and control license access for users within an organisation.
User account	The unique email and password credentials each person uses to log in to Aura and access processing seats.

3.3 Emesent User Management

Emesent User Management is a secure, web-based platform for managing access to Emesent software and services. It provides a central location where organization administrators can manage users and their access rights.

All Users Can:

- View user details, including name, email, and status (active or invited).



- Invite additional users.

Administrators Can:

- Invite new users or other administrators.
- Assign or revoke access to Aura login.
- Grant or remove user or administrator privileges.



Only users with email addresses that match the organization's domain can be invited. The table below provides examples.


Condition	Example	Allowed?
Email address ends with mycompany.com	user@mycompany.com	Yes
Email address does not match organization domain	user@othercompany.com	No

3.3.1 How to access the Emesent User Management

This procedure is used to access the Emesent User Management to manage user accounts and permissions.


User Management can be accessed at <https://manage.emesent.com/> or through Aura as follows:

1. Open **Aura** from your desktop or start menu.
2. Open the **User Profile** menu by clicking the icon in the top-right corner.
3. Select **Manage Users** from the dropdown menu.



4. The **Emesent User Management** opens in your default web browser.
5. Sign in with your **Emesent account credentials**.





Enter Your Password

Enter your password for Emesent to continue to Emesent Cloud Webapp

example.user@emesent.co Edit


Password*
..... 👁

Forgot password?

Continue

Don't have an account? Contact your administrator or Emesent to be invited to an Emesent account.

6. Press continue to open the user Management

🏠  Company Example Co EX

User Search

REMOVE USERS (0) INVITE


<input type="checkbox"/>	First Name	Last Name	Email	Role	User Status	Actions
<input type="checkbox"/>	Example	User	example.user@emesent.co	Admin	active	⋮
<input type="checkbox"/>	Example	User 1	example.user1@emesent.co	User	active	⋮
<input type="checkbox"/>	Example	User 2	example.user2@emesent.co	User	active	⋮



3.3.2 How to invite a new user

This procedure is used to invite new users so they can log in and process data in Aura under your organization's license.

1. From the User Management click **Invite** on the right-hand side of the interface.



2. Enter the user's **email address**
3. Use the dropdown to assign the user's role:
 - o **Admin:** Can invite or remove users and assign roles.
 - o **User:** Can access Aura but cannot manage users.



Home icon, emesent logo, Company: Example Co

Users / Invite

Email *
example.user3@emesent.co

7 remaining users can be invited to your company's account

User dropdown menu (Admin, User selected)

ADD button

Email

No rows

INVITE

- 4. Click **Add** to place the user into the pending invitations list.
 - Users are not invited immediately. Repeat Steps 2-4 to add multiple users before sending invitations.

Users / Invite

Email *
exmaple.user3@emesent.co

User dropdown menu

ADD button

6 remaining users can be invited to your company's account.

i The number of remaining users that can be added is displayed below the invite form. By default, each license allows up to 10 users.

- 5. Once all desired users have been added, click **Invite**.



- An invitation email will be sent to each user added in Step 5.

Company Example Co

Users / Invite

Email* User ADD

5 remaining users can be invited to your company's account.

Email	Role	
example.user3@emesent.co	User	DELETE
example.user4@emesent.co	Admin	DELETE

INVITE

3.3.3 How to resend or revoke an Invitation

This procedure is used to resend invitations to users who have not responded, or to revoke invitations that are no longer valid.

1. From the **User Management** home page, locate the user who has not accepted their invitation.
2. Click the **Actions** menu (three dots in the far-right column).
3. Select **Resend** or **Revoke Invite**. A success message will appear at the bottom of the screen if the action is completed successfully.
 - **Resend:** Sends a new invitation email to the user.
 - **Revoke:** Cancels the invitation. The original link will no longer work, and if the user clicks it, they will be notified that their invitation has been revoked.



Home | emesent | Company: Example Co | Ex

User Search

4 of 10 users added

Search [] REMOVE USERS (0) INVITE

<input type="checkbox"/>	First Name	Last Name	Email	Role	User Status	Actions
<input type="checkbox"/>	Example	User	example.user@emesent.co	Admin	active	⋮
<input type="checkbox"/>	Example	User 1	example.user1@emesent.co	User	active	⋮
<input type="checkbox"/>	Example	User 2	example.user2@emesent.co	User	active	⋮
<input type="checkbox"/>			example.user4@emesent.co	Admin	Invited	⋮

Send Invitation
Revoke Invitation

3.3.4 How to change a users role

This procedure is used to update a user’s role to adjust their level of access, such as granting administrator rights or limiting access to standard user functions.

1. From the **User Management** home page, locate the user whose role you want to change.
2. Click the **Role** dropdown in the far-right column.
3. Select a role:
 - o **Admin**: Can invite or remove users and assign roles.
 - o **User**: Can access Aura but cannot manage users.
4. Wait a few seconds for the role change to apply.



Home icon | emesent | Company: Example Co | Ex

User Search

3 of 10 users added

Search [] REMOVE USERS (0) INVITE

<input type="checkbox"/>	First Name	Last Name	Email	Role	User Status	Actions
<input type="checkbox"/>	Example	User	example.user@emesent.co	Admin	active	⋮
<input type="checkbox"/>	Example	User 1	example.user1@emesent.co	User	active	⋮
<input type="checkbox"/>	Example	User 2	example.user2@emesent.co	Admin	active	⋮

Dropdown menu for 'Admin' role: Admin, User

3.3.5 How to remove a user

This procedure is used to permanently remove a user’s access to Aura through the User Management .

1. From the **User Management** home page, locate the user you want to remove.
2. Click the **Actions** menu (three dots in the far-right column).
3. Click **Remove**.

Home icon | emesent | Company: Example Co | Ex

User Search

3 of 10 users added


Search [] REMOVE USERS (0) INVITE

<input type="checkbox"/>	First Name	Last Name	Email	Role	User Status	Actions
<input type="checkbox"/>	Example	User	example.user@emesent.co	Admin	active	⋮
<input type="checkbox"/>	Example	User 1	example.user1@emesent.co	User	active	⋮
<input type="checkbox"/>	Example	User 2	example.user2@emesent.co	User	active	⋮

Dropdown menu for 'User' role: Remove




- 4. Click Remove to confirm removal to immediately remove the user's access.



4. Emesent Aura User Interface

4.1 User Profile menu

The **User Profile menu**, located in the top-right corner of Aura, is used to log in and out of your Emesent account, view and manage licence details, and access the Emesent User Management Portal.





4.1.1 Log in and Log out

You can log in or log out of Aura using the **User Profile menu** in the top-right corner of the interface. Logging in connects your Emesent account to your organisation's shared licensing pool. Logging out releases any active licence and ends your current session.

4.1.2 Licence Details

The **Licence Details** panel displays information about your organisation's allocated seats. You can view the:

- Licence ID
- Assigned modules (e.g. SLAM, RTK, GCP)
- Licence expiry dates
- Current seat usage status

You can also manually **check out** a licence for offline use or **check it back in** when no longer needed.

4.1.3 User Management

The User Management opens in an external browser. For detailed instructions, refer to the Emesent Knowledge Base article on using Emesent User Management.

4.2 Context Panel

The Context Panel enables you to make further modifications to your processed point cloud or GCP data. The available settings vary depending on the selected file in the **Visualize** tab. The Context panel can be docked to the left or right of the screen or made as a floating panel. Refer to the docking instructions found in the [Visualize Tab](#) section for more information.

 There is no associated **Context** panel for meshes.

4.2.1 Point Clouds

There are two panels available when you select a point cloud. These panels can either be docked together or displayed separately.



4.2.1.1 Point Cloud Visualization

These settings help customize the point cloud's appearance to suit specific analysis requirements or highlight crucial details for better understanding and interpretation of the dataset.






Table 1 Context Panel - Point Clouds

Field	Data
Shape	<ul style="list-style-type: none"> • Square: Each point is shown as a square. • Circle: Each point is shown as a circle.
Colorization	<p>If toggled on, no Color Scale or Scalar Gradient is available, as colorization overrides these options.</p> <p>If you can't toggle on colorization, this means that you have a file that hasn't been colorized.</p>
Color Scale	<p>The color scale specifies filtering settings for the following scalar fields:</p> <ul style="list-style-type: none"> • Solid: A solid color, with no gradient. Choose this option for better contrast between selected points and the rest of the point cloud. This option can also provide more contrast against the background. • Elevation: Shows the elevation of each point in the point cloud. The color scale goes from blue (low elevation) to red (high elevation). • Position: Colors your point cloud on all three axes (X, Y, and Z). The X axis is blue, the Y axis is red, and the Z axis is green. • Classification: Colors your point cloud based on classifications, objects that have been identified (such as pipes) will be shown in randomized color selections. Currently, classification can not be generated by Aura. • Intensity: Shows the intensity of each point in the point cloud. This is particularly useful for detecting targets in your point cloud. • Time: Shows the time that each point was collected during the scan. • Ring: Shows primary colors, one for each of the Hovermap lasers. This option can be used for calibration, to check that all lasers are present in the scan data.



Field	Data
	<ul style="list-style-type: none"> • Range: Shows the distance of each point from Hovermap. • Return: Shows the laser strength and return order. This can be used for troubleshooting and point cloud cleaning. <div style="border: 1px solid #0070C0; padding: 10px; margin: 10px 0;"> <p>i Emesent Aura can detect the contents of the point cloud file and apply the appropriate color scale filter. Only the appropriate filters will appear in the dropdown list. For example, the Ring option will only be available for Emesent scans, as it detects information from Hovermap. If you have imported a third-party scan, the Ring option will not be available.</p> </div>
Point Scale	<p>Controls the size of each point. If the point size is set to 0, the points will appear as pixels (instead of the shape chosen in the Shape field).</p> <p><i>Default setting: 1</i></p>
Scalar Gradient	<p>This option gives you a range of color ramps to choose from. It is available on all attributes except when Classification, Position, or Solid color scale is selected.</p>
Scalar Filter	<p>The option is available when the Intensity, Time, Elevation, Return, or Range color scale is selected.</p> <p>A histogram chart allows you to visualize the intensity, time, or range distribution of your data. You can move the stops at each end of the graph to control how the color is presented, and specify histogram min. and max. values with an input value.</p>
Scalar Range	<p>The Scalar Range is the slider that sits below the graph. You can adjust the upper and lower stops to show a specific range of data.</p> <p>For example, if you only want to see points with an intensity between 100 and 200, you can adjust the stops to show only that range of data.</p>



4.2.1.2 Point cloud properties

If the selected point cloud is georeferenced, this panel displays the number of points and other important information such as transformations, scaling, and offsets applied to ensure accurate spatial representation.




Table 2 Context Panel - Point Clouds

Information	Description
Points	The number of points in the point cloud dataset (total number of points if multiple point clouds are selected).
Projection Information	Provides details about how the point cloud data is represented spatially.
Coordinates	The geographic coordinates indicating its global position.
Transformations	Shows the scaling factor and the offsets applied to coordinates.



Information	Description
Origin offset	The translation or displacement applied to the point cloud data's origin.
Bounding box	The dimensions of the bounding box around the point cloud data in each direction (X, Y, Z axis).

4.2.2 Ground Control Points

The Context panel for GCPs contains tools to help you georeference your point cloud.


4.2.2.1 Edit Constellation

A constellation is a set of coordinates that represent the real-world locations of the targets that were used during scanning. Emesent Aura attempts to automatically match targets of the appropriate size and intensity to locations within this constellation. This list allows you to choose which potential target identified in the point cloud is associated with which landmark in your constellation.

i A landmark can have multiple GCP targets associated with it to provide redundancy and improve accuracy.






Setting	Description
1. Show/Hide Landmark	Toggles between showing or hiding the selected landmark from the Viewport.
2. Show/Hide Target	Toggles between showing or hiding the selected target from the Viewport.
3. Expand/Collapse	Toggles between showing just the landmark or the landmark and its associated targets. This is useful if you have a long list of coordinates.
4. Focus	Zooms in on the selected target on the Viewport.
5. Remove Target	<p>Removes the selected target from the constellation and moves it to the Inactive Targets list. This can be useful in situations where the target was incorrectly identified during the initial georeferencing process.</p> <p>Refer to the GCP Workflow section for more information on matching targets to the correct landmark.</p>
6. Deactivate Landmark	<p>Removes the selected landmark and its associated target(s) from the constellation. It is important to exercise caution when using this function to ensure that you are removing the correct landmark and that it will not adversely affect the overall accuracy and alignment of the point cloud. When prompted, click Deactivate to confirm the removal.</p>
7. Save Constellation	Saves the changes you made to the constellation file.
8. Quick Save	<p>This option is only available when running the GCP processing workflow. If you use the Quick Save option, the saved file will overwrite the constellation.yaml file that was originally produced during processing. This is important, as Emesent Aura will look for this file to run the next steps in the process.</p> <div data-bbox="557 1601 1377 1727" style="border: 1px solid #0070C0; border-radius: 10px; padding: 10px; margin-top: 10px;"> <p> If you open an existing GCP project, the Quick Save option will not be available.</p> </div>



4.2.2.2 Inactive Landmarks

This list contains identified landmarks that have not yet been matched to any target in the constellation. When aligning point cloud data to a known coordinate system using GCPs, Aura will detect landmarks within the point cloud but they may not be suitable as GCP targets. You can choose to delete these landmarks before GCP data processing. If not, these will be listed as inactive landmarks in the Context panel so you can add them to the constellation if required.




Setting	Description
1. Show/Hide Inactive Landmark	Toggles between showing or hiding the selected landmark from the Viewport.
2. Focus	Toggles between showing or hiding the selected inactive landmark from the Viewport.
3. Add to Constellation	Moves the selected inactive landmark to the Edit Constellation list. You can then assign a target to the newly added landmark by dragging the target to the field below it.



4.2.2.3 Inactive Targets

This list contains identified targets that have not yet been matched to any landmark in the constellation. Any targets left in the **Inactive targets** list will be disregarded when reprocessing the point cloud.




Setting	Description
1. Show/Hide Inactive Targets	Toggles between showing or hiding the selected inactive target from the Viewport.
2. Add Target	Creates a new target. Select an area of points and click the Add Target button to create a new target.
3. Trash Target	Deletes the selected inactive target. It is important to exercise caution when deleting a target as you will not be able to recover it once deleted. When prompted, click Delete to confirm deletion.



4.3 Process Tab

You can use the **Process** tab to start a scan processing job (workflow) or view the **Processing Queue**.


i Refer to the [Visualize Tab](#) section for docking instructions or making the panel float on the screen.



4.3.1 Configure New Scan Job Panel


Clicking on **Process Scan** displays the **Configure New Scan Job** panel, which allows you to process a point cloud or GCP data. Once processed, enhance your scans using the **Merge** or **Colorize** features. You can then load these processed scans for editing in the **Visualize** tab.

For instructions on how to process a scan, refer to the [Working with Point Clouds](#) section.




4.3.2 Processing Queue

The **Processing Queue** lists all current, pending, failed, and completed workflows. The first section displays the overall percentage of completed workflows to those remaining in the queue.



4.3.2.1 Processing


All current and pending workflows are shown in the **Processing** section. Each workflow shows the folder name where the output files are saved. Clicking on **View Workflow** displays the progress of that particular workflow at the bottom.



4.3.2.2 Completed

Once the processing is finished, the workflow is moved to the **Completed** section.


- Click **View Files** to open a panel at the bottom, which lists the generated output files.
- Click **Open Folder** to open the folder where the generated output files are saved.
- Click **View** beside the output file to display it in the **Viewport**. Doing this also loads that particular output file in the **Visualize** tab so you can edit it further.
- Click **Close** to exit from the panel.





4.3.2.3 Failed

Any workflow that is processed unsuccessfully is displayed in the **Failed** section. A general error description is also provided.




i If the Aura application closes unexpectedly or the scan you are processing in Aura won't complete, it's important to [Recover Aura log files](#), generate a DirectX Diagnostic file, and report the incident through the [Customer Support form](#) online.

4.3.3 Processing Settings

Select a workflow then click **Processing Settings** to access advanced customization settings. In addition to the **General** and **Output** tabs, an additional tab specific to the selected workflow may be available.

4.3.3.1 General Tab





Mode Spherical

Radius 1.5

Trim data

Start delay 0

End cutoff 0

Georeferencing

Georeferencing mode None

Point filtering

ST-X noise filtering ?

Adaptive SOR ?

Nearest neighbor ? 50 5 100

Alpha ? 0.1 0 2

Denoise SOR ?

Nearest neighbor ? 50 5 100

Log scale ? 6 2 10

Moving object filtering ?

Surface noise reduction ?

LOW **MEDIUM** **HIGH** ?

Limit corner rounding ?

Intensity 0 255

Range (m) 0 100

Advanced


RESET TO DEFAULT **SAVE** **CLOSE**



Table 3 Processing Settings - General Tab

Field	Data
Advanced feature matching	Enabling this stage of SLAM processing can improve results in most environments, but disabling it may provide better results in complex or repeating environments.
Exclusion Zones	<p>You can use this setting to exclude points close to Hovermap that may interfere with the SLAM algorithm or add noise to the point cloud (for example, those created by Hovermap itself, a drone, vehicle, or operator). We recommend that you use the default setting.</p> <p>Mode:</p> <ul style="list-style-type: none"> • Bounding Box: This option allows you to configure the minimum and maximum distance <i>on each axis</i>. <ul style="list-style-type: none"> ○ X Min / Forward: Points within this minimum distance <i>at the front of</i> Hovermap are not processed. <i>Default setting: 1.5 m</i> ○ X Max / Backwards: Points within this maximum distance <i>at the back of</i> Hovermap are not processed. <i>Default setting: 1.5 m</i> ○ Y Min / Left: Points within this minimum distance <i>to the left of</i> Hovermap are not processed. <i>Default setting: 1.5 m</i> ○ Y Max / Right: Points within this maximum distance <i>to the right of</i> Hovermap are not processed. <i>Default setting: 1.5 m</i> ○ Z Min / Down: Points within this minimum distance <i>underneath</i> Hovermap are not processed. <i>Default setting: 1.5 m</i> ○ Z Max / UP: Points within this maximum distance <i>on top of</i> Hovermap are not processed. <i>Default setting: 1.5 m</i>



Field	Data
Trim Data	<p>Use this setting to specify the time (in seconds) to ignore data from either end of your dataset. This can be useful, for example, if your scan gets off to a difficult start.</p> <ul style="list-style-type: none"> • Start Delay: The number of seconds to be dismissed from the beginning of the scan. • End Cutoff: The number of seconds to be dismissed from the end of the scan (working backward).
Georeferencing	<ul style="list-style-type: none"> • Georeferencing Mode: Select the method used to obtain location data for accurately referencing the point cloud in real-world coordinates. <ul style="list-style-type: none"> ◦ Drone RTK / Vehicle RTK / Backpack RTK: Select the device used to capture the scan data. ◦ GPS: Use standard GPS data without real-time correction through RTK. This could still provide reasonably accurate georeferencing but might not achieve the same level of precision as RTK.
	<ul style="list-style-type: none"> • OGC WKT Standard: Select the Well-Known Text (WKT) format, which is used to represent coordinate reference systems and transformations. WKT provides a standardized way to describe spatial reference systems in a textual format. <ul style="list-style-type: none"> ◦ WKT1: The original version of the Well-Known Text format. It describes coordinate reference systems and coordinate transformations in a textual representation and is widely used in various geospatial applications. ◦ WKT2.2018: An updated version of the Well-Known Text standard released in 2018. This version includes improvements, additional functionalities, and other updates. • GNSS receiver type: The GNSS receiver used to capture the RTK data. <div data-bbox="517 1664 1377 1870" style="border: 1px solid gray; padding: 10px; margin-top: 10px;"> <p> For optimal results, ensure that the Georeferencing mode and GNSS receiver type match the hardware used during data collection. While the resulting point cloud remains usable, the accuracy may be compromised.</p> </div>



Field	Data
Base coordinate reference system	Select the CRS in which the data was originally collected. This information is essential for accurate transformations and reprojections to the target CRS.
Reprojection	<p>Toggle on to reproject the point cloud being processed.</p> <ul style="list-style-type: none"> • Horizontal: Reproject to a different map projection or coordinate system. • Vertical: Convert from ellipsoidal height to orthometric height using a GEOID model.
Point Filtering	<p>You can integrate automated filtering into the processing workflow by enabling any of the following noise filters. This may eliminate the need for a separate filtering step after processing. Note that only default settings are used, there are no options to adjust the filtering parameters.</p> <p>Refer to the Main Toolbar section for more information on each filter and its associated parameters.</p> <ul style="list-style-type: none"> • STX Noise Filtering: Filters out stray points by analyzing the range, intensity, and number of LiDAR points returned. Keep in mind that this process only applies to data collected from a Hovermap ST-X and will not have any effect on point cloud data gathered from other Hovermaps. • Adaptive SOR: Removes points that seem fuzzier than nearby points such as noise thickness from walls and floors. <ul style="list-style-type: none"> ○ Nearest neighbor: The number of point neighbors used for evaluation. A lower setting will result in quicker processing times but removes less sparse noise. ○ Alpha: Threshold for noise filtering. A lower setting will result in more aggressive filtering. • Denoise SOR: Removes outlier point which are less likely to be real such as reflections. <ul style="list-style-type: none"> ○ Nearest neighbor: The number of point neighbors used for evaluation. A lower setting will result in quicker processing times but removes less sparse noise. ○ Log scale: Threshold for noise filtering. A lower setting will result in more aggressive filtering.



Field	Data
	<ul style="list-style-type: none"> • Moving object filtering: Removes moving points over 5 second intervals and keeps fixed point in the environment. <ul style="list-style-type: none"> ◦ Motion level: Detects movement over 5 second intervals. The higher the value, the lesser moving points are selected. ◦ Distance: The maximum distance for recovering fixed points. The higher the value, the more points are selected. A value of 1 to 2 cm are recommended for most scans.
	<ul style="list-style-type: none"> • Surface Noise Reduction: Applies a smoothing filter to the point cloud, reducing noise and increasing point cloud precision. Processing time will vary per selection level. <ul style="list-style-type: none"> ◦ Low: Best for dense scans (for example indoors). Results in fast processing and low corner rounding. ◦ Medium: Ideal for semi dense scans. May improve results in areas with lower point density. ◦ High: Best for sparse scans (for example outdoors). Results in slower processing and higher corner rounding.
	<ul style="list-style-type: none"> • Limit Corner Rounding: Reduces rounding of corners when point noise reduction is applied. Corners may have more noise when limit corner rounding is turned on.
	<ul style="list-style-type: none"> • Intensity: Set the minimum and maximum intensity values of points to be written to the output point cloud. • Range: Set the minimum and maximum range values of points to be written to the output point cloud.
Reset to Default	Reset all settings to the default.
<p>Advanced</p> <p>The advanced settings contain additional processing parameters that can be adjusted to improve the output of the SLAM algorithm in certain circumstances. You should only use these settings when you are unable to achieve a quality output using the standard processing profiles.</p> <p>We recommend that you only use these settings after talking to Customer Support.</p>	



Field	Data
Local mapping	
Time Window (Auto SLAM)	<ul style="list-style-type: none"> Time Window Sliding Size in Seconds: The length of the sliding window when running the optimization part of the SLAM process. Increase this value to improve the chance of a good output when there are a low number of geometric features in the scan. Increasing this number comes at the cost of increasing the processing time. <i>Default setting: 5 seconds</i> Time Window Sliding Shift in Seconds: Indicates how far the above window is shifted in each optimization loop. Decrease this value to improve the chance of a good output when there are a low number of geometric features in the scan. Decreasing this number comes at the cost of increasing the processing time. <i>Default setting: 1 second</i> Auto SLAM dynamically adjusts the Time Window processing parameters in real time when encountering challenging environments, such as tunnels, culverts, or expansive open areas with minimal geometric features. The parameter values configured in the user interface serve as optimal-case constraints; Auto SLAM will only exceed these thresholds when required to maintain tracking performance. This feature eliminates the need for manual intervention in most cases, such as switching to the "Low Feature" profile or modifying time window settings.
Point Filtering	<ul style="list-style-type: none"> Intensity: Set the minimum and maximum intensity values of points to be written to the output point cloud. The defaults have been chosen to ensure that noise points from the sun are excluded. We recommend that you use the default settings. <i>Min default setting: 0</i> <i>Max default setting: 255</i> Range: Set the minimum and maximum range values of points to be written to the output point cloud. The default values include all points out to the maximum range of the LiDAR. <i>Min default setting: 0</i> <i>Max default setting: 300</i>



Field	Data
Iterations	<ul style="list-style-type: none"> • Local Iterations: The maximum number of iterations that the main optimization loop performs during local mapping. Use this when you want to reduce local slips. Increasing this number will cause processing to take longer. <i>Default setting: 5</i> • Local Iterations Internal: The maximum number of iterations that the internal optimization loop performs during local mapping. Use this when you want to reduce local slips. Increasing this number will cause processing to take longer. <i>Default setting: 5</i>
Voxels	<ul style="list-style-type: none"> • Voxels Size: The lowest size of voxel used to generate surfels in SLAM. Use this inside smooth tunnels/bores, as most of the information within the points will be in the subtle variations in the surface direction that occur in relatively small dimensions. Increasing this number can significantly increase processing time. <i>Default setting: 0.4 m</i> • Voxel Levels: The number of levels used to generate surfels in SLAM. Each level is twice the size of the previous level. Use this inside tunnels/bores, as most of the information within the points will be in subtle variations in the surface direction that occur in relatively small dimensions. <i>Default setting: 5</i> • Voxel Minimum Points: The minimum number of points in a voxel to use for SLAM. Use this to reduce the impact of noisy data on SLAM, or to ensure that features with a low number of points are included in environments with few geometric features. <i>Default setting: 8</i>



Field	Data
Global registration	
Point Filtering	<ul style="list-style-type: none"> Intensity: Set the minimum and maximum intensity values of points to be written to the output point cloud. The defaults have been chosen to ensure that noise points from the sun are excluded. To include all points, use the default settings. <i>Min default setting: 0</i> <i>Max default setting: 255</i> Range: Set the minimum and maximum range values of points to be written to the output point cloud. The default values include all points out to the maximum range of the LiDAR. <i>Min default setting: 0</i> <i>Max default setting: 300</i>
Iterations	<ul style="list-style-type: none"> Global Iterations: The number of loops performed as part of the global registration process. Use this to reduce global slips. Increasing this number increases the likelihood of a quality output, but it will significantly increase processing time. <i>Default setting: 10</i> Global Iterations Internal: The minimum number of iterations required to complete SLAM.



Field	Data
<p>Voxels</p>	<ul style="list-style-type: none"> <p>• Voxel Size: The lowest size of voxel used to generate surfels in SLAM. Use this inside smooth tunnels/bores, as most of the information within the points will be in the subtle variations in the surface direction that occur in relatively small dimensions. Increasing this number can significantly increase processing time. <i>Default setting: 0.4 m</i></p> <p>• Voxel Levels: The number of levels used to generate surfels in SLAM. Each level is twice the size of the previous level. Use this inside tunnels/bores, as most of the information within the points will be in subtle variations in the surface direction that occur in relatively small dimensions. <i>Default setting: 5</i></p> <p>• Voxel Minimum Points: The minimum number of points in a voxel to use for SLAM. Use this to reduce the impact of noisy data on SLAM, or to ensure that features with a low number of points are included in environments with few geometric features. <i>Default setting: 100</i></p>
<p>Velocity</p>	<ul style="list-style-type: none"> <p>• Local Linear Velocity Confidence: Allows you to decide how much confidence the global registration stage should place in the linear velocity results of the local mapping stage. The number is measured in standard deviation/error, so the higher the number, the lower the confidence. This is useful, for example, for long driving scans (over 500 m), where the start and end of the scan should overlap, but do not do so cleanly, or where there are sharp changes in the trajectory that are inconsistent with the actual scan. Significantly decreasing these values can help to keep the trajectory from being snapped to the correct global slips. <i>Default setting: 0.5</i></p>



Field	Data
	<ul style="list-style-type: none"> Local Angular Velocity Confidence: Allows you to decide how much confidence the global registration stage should place in the angular velocity results of the local mapping stage. The number is measured in standard deviation/error, so the higher the number, the lower the confidence. <i>Default setting: 0.8</i>
Matching	<ul style="list-style-type: none"> Number of Matches: Set the number of voxel matches that the SLAM algorithm will search for within the given restrictions. Increase this value to make the global registration more aggressive in searching for matching voxels and then adjusting the trajectory to make similar areas overlap. This is useful for long driving scans, where increasing the number of global iterations fails to get the start and end of the scan to align. Increasing these values usually requires decreasing the Local linear Velocity Confidence and the Local Angular Velocity Confidence values. <i>Default setting: 5</i> Max Distance: The maximum distance (in voxel units) that the SLAM algorithm will search for voxel matches. Increase this value to make the global registration more aggressive in searching for matching voxels and then adjusting the trajectory to make similar areas overlap. <i>Default setting: 10</i>



4.3.3.2 GCP Tab




Table 4 Processing Settings - GCP Tab

Field	Data
Wait for GCP Target Manual Review	Select this checkbox to pause the software while the targets are confirmed. <div style="border: 1px solid #007bff; padding: 10px; margin: 10px 0;"> <p>i If unselected, Emesent Aura will assume that the constellation of detected targets has been successfully matched to the survey points provided.</p> </div>
Point Filtering	Intensity: The filter intensities should be between 150 and 255, assuming no change to the target material.



Field	Data
Detection	<p>These parameters help to identify a target.</p> <ul style="list-style-type: none"> • Number of Points: The minimum number of points required before a cluster (in the global and local stage) can be considered a target. • Target Thickness: The maximum thickness of the cluster of points representing the target. • Target Standard Deviation: Specifies target thickness. It helps to detect and identify targets more accurately. As this number increases, GCPs will be more easily detected. <i>Default setting: 0.003 m (3 mm)</i>
Reset to Default	Reset all settings to the default.

4.3.3.3 Merge Tab







Table 5 Processing Settings - Merge Tab

Field	Data
Voxels	<ul style="list-style-type: none"> • Voxels Size: The lowest size of voxel used to generate surfels in SLAM. Use this inside smooth tunnels/bores, as most of the information within the points will be in the subtle variations in the surface direction that occur in relatively small dimensions. Increasing this number can significantly increase processing time. <i>Default setting: 0.4 m</i> • Voxel Levels: The number of levels used to generate surfels in SLAM. Each level is twice the size of the previous level. Use this inside tunnels/bores, as most of the information within the points will be in subtle variations in the surface direction that occur in relatively small dimensions. <i>Default setting: 5</i> • Voxel Minimum Points: The minimum number of points in a voxel to use for SLAM. Use this to reduce the impact of noisy data on SLAM, or to ensure that features with a low number of points are included in environments with few geometric features. <i>Default setting: 8</i>
Matching	<ul style="list-style-type: none"> • Number of Matches: Number of surfels to look for matches during SLAM. • Max Distance: Maximum distance (in voxels) to search for surfel matches.



Field	Data
Georeferencing	<ul style="list-style-type: none"> • Georeferencing Mode: Select the method used to obtain location data for accurately referencing the point cloud in real-world coordinates. <ul style="list-style-type: none"> ◦ Drone RTK / Vehicle RTK: A satellite navigation technique used to enhance the precision of position data obtained from GPS (Global Positioning System). It relies on a fixed base station and a mobile receiver. The base station precisely knows its location and communicates correction signals to the mobile receiver. Select this mode to allow the point cloud data to be aligned and referenced using highly accurate, real-time corrected GPS signals obtained through RTK technology. <p>GPS: A satellite-based navigation system that provides location and time information anywhere on Earth. Choosing GPS as the Georeferencing Mode might mean that the software will use standard GPS data without real-time correction through RTK. This could still provide reasonably accurate georeferencing but might not achieve the same level of precision as RTK.</p> ◦ OGC WKT Standard: Select the Well-Known Text (WKT) format, which is used to represent coordinate reference systems and transformations. WKT provides a standardized way to describe spatial reference systems in a textual format. WKT1 is recommended for best compatibility. <p>WKT1: The original version of the Well-Known Text format. It describes coordinate reference systems and coordinate transformations in a textual representation and is widely used in various geospatial applications.</p> <p>WKT2.2018: An updated version of the Well-Known Text standard released in 2018. This version includes improvements, additional functionalities, and other updates.</p>



Field	Data
	<div style="border: 1px solid #0070C0; padding: 10px; background-color: #E6F2FF;"> <p> • For PLY and trajectory files in UTM or WGS84 coordinates, an additional PRJ file containing the projection information in OGC WKT format is written. LAS files contain the projection information in the file header.</p> <p>• If there is no GPS data recorded by Hovermap in the dataset, the output will only be in local coordinates, with the origin at the start of the scan.</p> </div>
Reset to Default	Reset all settings to the default.



4.3.3.4 Colorize Tab

PROCESSING SETTINGS

Colorize

Video time range (seconds) ?

Video time start

Video time end

Frame extract interval ?

Time (seconds) ?

Distance (m) ?

Angle (degrees) ?

Processing quality

Visibility voxel size ?

Colorization distance ?

Point color radius ?

Reduce blue sky bleeding ?

Image masking ?

Frame refinement

Review frame images before colorization ?

Output


Remove uncolored points Keep frame images

Advanced

Ignore validation errors ?




Table 6 Processing Settings - Colorize Tab

Field	Data
Video Time Range	<p>Sets the start and end time when frames are extracted from the video.</p> <div data-bbox="502 537 1380 739" style="border: 1px solid #0070C0; padding: 10px; margin: 10px 0;"> <p> The time represents the elapsed video time, not the number of seconds to trim from the end of the total video duration. Setting the Video end time to 0 will include everything after the start time.</p> </div>
Frame extract interval	<p>Uses the maximum time, distance, and angle to determine the number of video frames to skip between image extractions, keeping only the necessary images.</p> <ul style="list-style-type: none"> • Time: We recommended this setting is turned off to avoid repetitive extractions when the camera is not moving. The recommended range is between 1 to 20. • Distance: Extracts images based on the distance the camera travels to avoid repetitive images when standing still. The recommended settings are 1 to 2 for small, confined spaces and 5 to 10 for moving capture in open spaces. • Angle: Extracts images based on changes to the camera angle. The recommended settings are 10 to 15 degrees when using a perspective camera and 45 to 90 degrees when using a 360 camera.



Field	Data
Processing Quality	<ul style="list-style-type: none"> • Point Color Radius: Adjusts the occlusion size of the points for colorization. A smaller value may cause color of foreground objects to bleed onto background points, larger values may result in background points that are near foreground points not to get colored. The recommended range is between 0.01 and 0.03. • Visibility Voxel Size: Determines the resolution of 3D pixels (in meters). A lower setting results in finer colorization quality and increased processing time. The recommended range is between 0.01 and 0.1. • Colorization Distance: Adjusts the maximum distance of points from the GoPro camera to be colorized. A higher setting results in more points being colorized and increased processing time. The recommended range is between 10 and 300.



Field	Data
<p>Reduce blue sky bleeding</p>	<p>Allows you to reduce and mask out the color bleed or the blending of blue or gray sky on buildings and other objects.</p> <ul style="list-style-type: none"> Strength: Adjust the intensity of the filter to mask the blue or gray sky. Use the Low setting for clear blue skies. For gray overcast conditions or scenes with complex features like trees, varying colors, or cloud patterns, a Medium to High setting is recommended. Note that higher strength settings may increase the likelihood of masking light-colored buildings. <p>Alternatively, toggle on the Advanced option and configure the following:</p> <ul style="list-style-type: none"> RGB blue: Set the minimum value of the blue channel to detect blue sky. A value of 200 is recommended for most sky types, 120 for blue skies with light-colored buildings, and 150 for low-light conditions such as dawn and dusk. Gray intensity: Used to detect gray sky. A value of 0 is ideal for blue skies, 20 for overcast (gray skies), and 50 for darker gray clouds. Higher values may result in unintentional masking of gray or light-colored buildings. Color detection: Identifies and masks colors with the specified RGB values. Use a setting of 25 for detecting gray skies, 35 for blue or light blue skies, 50 for blue skies with trees, and 75 for gray clouds with trees. Note that higher values may lead to unintentional masking of gray or light-colored buildings.
	<div style="border: 1px solid #0070C0; padding: 10px; background-color: #E6F2FF;"> <p> When reviewing the frames between extraction and colorization, you should see the sky effectively masked in most frames. Some frames might still show minor visible patches of sky or unintended masking of building parts, but this should not impact the final colored point cloud significantly if these issues occur only occasionally. In cases like these, it is generally better to increase the filter strength rather than decrease it, as remaining bits of visible sky are more likely to be noticeable in the final point cloud than a few mistakenly masked building parts, especially if the building is clearly visible in other frames.</p> </div>



Field	Data
Image Masking	This allows you to hide unwanted features from all your extracted frames. Choose from the available mask templates depending on the accessory/ platform you are using. To create your own, Refer to the Creating a Custom Mask section for instructions.
Output	<ul style="list-style-type: none"> Remove Uncolored Points: This allows you to include or exclude points from the original scan that could not be colorized. <i>Default setting: Unselected</i> Keep Frame Images: This allows you to keep or remove the GoPro image frames from the colorization output folder. Select this option to use image frames and pose data in third-party software. De-select this option to save hard drive space. <i>Default setting: Selected</i>
Advanced	<ul style="list-style-type: none"> Ignore Validation Errors: Ignore any errors that are detected during input data validation. Only use this if you are sure that your inputs are correct as it may lead to failed or unusable results.
Reset to Default	Reset all settings to the default.

4.3.3.5 Extract 360 Images Tab






Table 7 Processing Settings - Extract 360 Images

Field	Data
Video Time Range	<p>Sets the start and end time when frames are extracted from the video.</p> <div style="border: 1px solid #0070C0; padding: 10px; margin: 10px 0;"> <p>i The time represents the actual elapsed video time, not the number of seconds to trim from the end of the total video duration. Setting the Video end time to 0 will include everything after the start time.</p> </div>
Frame extract interval	<p>Uses the maximum time, distance, and angle to determine the number of video frames to skip between image extractions, keeping only the necessary images.</p> <p>Time: It is recommended to turn this setting off to avoid repetitive extractions when the camera is not moving. The recommended range is between 1 to 20.</p> <p>Distance: Extracts images based on the distance the camera travels to avoid repetitive images when standing still. The recommended settings are 1 to 2 for small, confined spaces and 5 to 10 for moving capture in open spaces.</p> <p>Angle: Extracts images based on changes to the camera angle. The recommended settings are 10 to 15 degrees when using a perspective camera and 45 to 90 degrees when using a 360 camera.</p>
Camera orientation override	<p>Allows you to configure the camera’s orientation settings manually.</p> <ul style="list-style-type: none"> • Roll: Configure the rotation around the front-to-back axis. • Pitch: Configure the rotation around the side-to-side axis. • Yaw: Configure the rotation around the side axis.
Image Masking	<p>This allows you to hide unwanted features from all your extracted frames. Choose from the available mask templates depending on the accessory/platform you are using. To create your own, Refer to the Creating a Custom Mask section for instructions.</p>



4.3.3.6 Output Tab




Table 8 Processing Settings - Output Tab

Field	Data
Point Cloud - output file types	<ul style="list-style-type: none"> • PointCloud LAZ (1.4): Output a point cloud in compressed LAS 1.4 format <i>Default: On</i> • PointCloud LAS (1.4): Output a point cloud in uncompressed LAS 1.4 format. <i>Default: Off</i> • E57: Output a point cloud in an E57 format. <i>Default: Off</i> • PointCloud LAZ (1.2): Output a point cloud in compressed LAS 1.2 format. <i>Default: Off</i> • PointCloud LAS (1.2): Output a point cloud in uncompressed LAS 1.2 format. <i>Default: Off</i> • PLY: Output a point cloud in PLY format. <div style="border: 1px solid #add8e6; padding: 10px; margin-top: 10px;"> <p>i You can select more than one option.</p> </div>



Field	Data
Subsampling	<ul style="list-style-type: none">• Subsample Point Clouds: Generate a subsampled point cloud for each of the selected options above. <i>Default: On</i>• Subsample Factor: The fraction of the points in the point cloud to sample. For example, 0.10 will output 10% of the points. <i>Default: 0.10</i>
Reset to Default	Reset all settings to the default.



4.4 Global Settings

These settings allow you to open and save files, open and save projects, set global preferences for viewing your point clouds, and capture screenshots. The following options are available.

4.4.1 Project Menu




Click the **Project Menu** icon on the top-left portion to access the following menu options.

Table 9 Project Menu Options


Menu	Description
Open	Opens a file and displays it in the viewport.
Open project	Opens a previously saved .aura project file.
Save	Saves the changes made to the current file.
Save as	Creates a copy of your current file with a different name, location, or file format.
Save project	Saves your current work for future modifications. The .aura project file serves as a starting point that can be reopened and edited whenever needed, allowing you to continue working on the project from where you left off.
Export reprojection	Reprojects a previously processed/reprojected point cloud into a new coordinate reference system and GEOID model.



4.4.2 Preferences



Click **Preferences** to see the global settings. Once you have configured the settings, click **Save** to apply the settings or **Close** to exit without saving. You can also click **Reset Preferences** to restore your preferences to their default settings.





The following options are available.



Table 10 Preferences Settings

Field	Data
Rendering	
Point Budget	<p>The total number of points allowed in the Viewport. The upper limit can change, depending on the number of points available in your point cloud. With a large point cloud, you may not see every point on your screen unless you expand this setting to its upper limit.</p> <p><i>Default setting: 7 million (for performance purposes)</i></p>
Camera Type	<ul style="list-style-type: none"> • Perspective: Objects that are far away appear smaller than those that are closer. The Perspective view is easier on the eye because you use it in real life. • Orthographic: All objects appear at the same scale, giving a clearer measure of distances between objects and their relative size. <p><i>Default setting: Perspective</i></p>
Near Clipping Plane	<p>Removes points from the Viewport that are closest to the camera. These points are not deleted, just not visible. This distance is configurable.</p> <p>This feature is useful if you want to look at a cross-section of your point cloud or look through a wall.</p>




Field	Data
Eye Dome Lighting (EDL)	<ul style="list-style-type: none"> • Enabled: Toggle on to enable eye dome lighting. This improves depth perception by shading the outline of points, accentuating the shape of each object. The point cloud can look a bit flat without this enabled. • Radius: The distance/thickness from the point being outlined. Setting the value to 1 outlines the pixels directly adjacent to the point, setting the value to 2 outlines the pixels 2 pixels away from the point and so on. • Bias: Controls the minimum depth difference between the points to be outlined. Setting the value to 0 means that any difference in depth will get outlined, while a higher bias value (e.g. 1) means that only points that are at least 1 world space units apart will be outlined. • Strength: Changes the strength of the outline. A higher strength setting makes the outlines darker, mostly noticeable on surfaces.



Field	Data
<p>Multi-Frame Rendering (MFR)</p>	<ul style="list-style-type: none"> <p>Enabled: Toggle on to enable multi-frame rendering screenshots, as well as the option to turn on live build-up. <i>Default setting: Enabled</i></p> <div data-bbox="568 519 1378 645" style="border: 1px solid #0070C0; border-radius: 10px; padding: 10px; background-color: #E6F2FF;"> <p> It will take a few seconds to create the screenshot with multi-frame rendering enabled.</p> </div> <p>Live Build-up: Toggle on to enable the live build-up of the full point cloud in the viewport. This setting allows you to navigate a dense point cloud more easily. MFR uses a lower point budget while navigating, but once you stop, it builds up to the full point budget available. This prevents lag and allows you to view your point cloud in detail. <i>Default setting: Enabled</i></p> <div data-bbox="568 1012 1378 1626" style="border: 1px solid #008000; border-radius: 10px; padding: 10px; background-color: #E6F2E6;"> <p></p> <ul style="list-style-type: none"> MFR works best with the point size set to 0. Setting the point budget too high with MFR enabled can result in poor responsiveness. The default value with MFR enabled is 3 million. Consider disabling MFR and increasing the point budget to 5 or 10 million when using point selection and measurement tools. There are a number of triggers that initiate re-rendering, including translate/rotate, camera zoom/pan, undo/redo, and changes to file attributes (such as point shape, color scale, or point size). </div>



Field	Data
	<div style="border: 1px solid #0070C0; padding: 10px; background-color: #E6F2FF;"> <p> • You can only enable this setting if Multi-Frame Rendering has been turned on.</p> <p>• We recommend that you don't use MFR when using selection or measurement tools when aligning point clouds using translate/rotate tools or during the GCP constellation matching stage.</p> </div>
View Defaults	
Zoom Speed	<ul style="list-style-type: none"> • Fast: Good for wide, open scans. • Medium: Good for underground scans. • Slow: Good for close inspection.
Selection Outline Color	Allows you to choose the color of the selection box using either the color picker or RGBA/HEX color codes.



Field	Data
Appearance	
Background	<p>Allows you to configure the background color of the viewport.</p> <p>The standard black background means that you can miss a lot of detail, especially when viewing colorized point clouds. You can now change the background color to make this detail more visible.</p> <ul style="list-style-type: none"> • None: No color selected. The background will be a standard black. • Solid: Allows you to choose a solid background color using either the color picker or RGBA/HEX color codes. • Gradient <ul style="list-style-type: none"> ○ Linear: Click the color at each end of the Gradient scale to choose a start and an end color. The gradient will be between these two colors. Move the Angle dial to change the angle of the gradient. ○ Corner: Allows you to specify individual colors for the top left, top right, bottom left, and bottom right of the Viewport.
Reset Preferences	Reset all settings to the default.



4.4.3 Capture Screenshot




Select **Capture Screenshot** to generate a screenshot of your current view. Your screenshot will be automatically saved in the **Documents\Emesent\Aura\Screenshots** folder.

If you have **Multi-Frame Rendering** enabled, a high-quality screenshot will be produced. All settings, such as GCP landmarks, will appear in the screenshot.


Click **Open** to open the folder containing your screenshot.

4.5 Viewport

Use the Viewport to navigate and manipulate your point cloud. The Viewport also shows live X/Y/Z mouse coordinates. Press the **F1 key** in Aura at any time to access Help and see the full range of mouse actions and keyboard shortcuts available to you.






 The bounding box shows the extent of your point cloud. You cannot interact with the bounding box but you can hide it by unselecting the the point cloud on the from the **Visualize** tab.



4.6 Main Toolbar

The Main Toolbar contains several tools for navigating and interacting with your point cloud. It can be docked to the top or bottom of the viewport (or it can be a floating panel). These tools are grouped based on usage. The icon displayed in the toolbar indicates the tool that has been selected for that group.








1. Navigate
2. Translate
3. Rotate
4. Axis Lock tools
5. Selection tools
6. Cleaning filters
7. 3D View menu
8. Measurement tools
9. Undo / Redo









The Undo/Redo function is only currently available for certain tools. If you need to make any major changes, we recommend that you first save your file using the **Save** or **Save as** options in the **Project Menu**.





Table 11 Main Toolbar

Button	Action
Navigate	
	<p>Navigate: Move around the point cloud, as opposed to <i>shifting</i> it. Left-click your mouse to choose the center of rotation. This point will be shown by a white ball.</p> <p>Double-click your mouse to lock the rotation on an exact point. The ball will turn orange. Double-click again to unlock.</p>
Translate	
	<p>Translate: Move your point cloud along different axes. Click on the arrow to choose which axis. Select the square to translate along <i>multiple</i> axes.</p>
Rotate	
	<p>Rotate: Click on the desired axis to rotate your point cloud around that axis.</p>
<p>Axis Lock</p> <p>Rotates your point cloud around the selected axis.</p> <p>Right-click and drag to translate along the locked axis.</p> <p>Double-click your mouse to lock the axis on an exact point. The ball will turn orange. You can change the axis while the ball is orange, and the new axis will rotate around the same point.</p> <p>Double-click again to release.</p>	
	<p>X Axis Lock: Locks the point cloud rotation to the X axis, which is represented by a red line.</p>
	<p>Y Axis Lock: Locks the point cloud rotation to the Y axis, which is represented by a green line.</p>




Button	Action
	<p>Z Axis Lock: Locks the point cloud rotation to the Z axis, which is represented by a blue line.</p>
<p>Selection tools</p>	
	<p>Select Points: Select and deselect points within the square selection box. This function is good for point cloud cleaning, as well as for selecting targets in the GCP workflow.</p> <p>Right-click your mouse, or press the Esc key to remove the selection.</p> <div data-bbox="643 779 1378 864" style="border: 1px solid #0070C0; border-radius: 5px; padding: 5px; background-color: #E6F2FF;"> <p> Not available when working with meshes.</p> </div>
	<p>Select Area: Select a 2D region (often represented as a polygon) in the point cloud to encompass multiple points within that defined area.</p> <p>Right-click your mouse, or press the Esc key, to remove the selection.</p> <div data-bbox="643 1169 1378 1254" style="border: 1px solid #0070C0; border-radius: 5px; padding: 5px; background-color: #E6F2FF;"> <p> Not available when working with meshes.</p> </div>
	<p>Select Volume: Define a 3D region or volume in the point cloud and select all points falling within that defined volume.</p> <p>When this tool is selected, the color of the point cloud changes to grayscale and a 3D bounding box becomes available. Drag the arrows in the bounding box to select all points within that volume.</p> <p>This selection tool is useful for tasks such as object extraction or isolating specific structures in the point cloud.</p>









Button	Action
	<p>Delete selection: Deletes any points you have selected.</p> <div data-bbox="643 416 1378 719" style="border: 1px solid #007bff; padding: 10px; margin: 10px 0;"> <p>i</p> <ul style="list-style-type: none"> • Not available when working with meshes. • Be careful, as there is no undo function available for this action. Be sure that you want these points deleted before you do so. </div>
<p>Cleaning Filters</p>	
	<p>Decimate by distance filter: Subsamples the point cloud by specifying the minimum distance allowed between points (measured in meters). You can either select or delete the points.</p> <p>This tool is useful when you want to thin out your point cloud to make it easier to navigate. The smaller the point cloud, the more responsive it will be. You may have to experiment with the settings to achieve the desired result.</p> <p>There are three input parameters:</p> <ul style="list-style-type: none"> • Minimum distance: Select the minimum distance between points. <i>Default setting: 0.01 (1 cm)</i> • Point decimated: Specify whether the points should be deleted or selected. <i>Default setting: Delete</i> • Invert: Inverts the selection calculated by the DBD algorithm. <div data-bbox="643 1581 1378 1666" style="border: 1px solid #007bff; padding: 10px; margin: 10px 0;"> <p>i Not available when working with meshes.</p> </div>








Button	Action
	<p>Classic SOR: Removes stray points in a dense point cloud. This filter works out the average distance of each point from its neighboring points. It then rejects the points that are farther than the average distance. All points outside of this distance are considered outliers and can be removed from the dataset. You may have to experiment with the settings to achieve the desired result.</p> <p>Denoise SOR: Removes noise in a dense point cloud. This filter analyzes the point cloud to identify points that are likely to be noise or outliers. Points that significantly deviate from the expected parameters are considered outliers and are removed from the dataset.</p> <p>Adaptive SOR: Adaptively removes outliers while considering variations in point density and noise levels across different regions of the point cloud dataset. This filter can be particularly useful in cases where the point cloud has varying levels of detail.</p> <p>The available parameters vary depending on the SOR type.</p> <ul style="list-style-type: none"> • Nearest neighbor: The number of neighboring points required to calculate the average distance for a given point. <i>Default setting: 6</i> • Alpha: If Adaptive SOR is selected, this setting controls the adaptability of the filter to local point density variations. A higher value leads to more adaptive thresholding and can be useful for handling data with varying point density. A lower value might make the filter less sensitive to density changes and provide a more uniform filtering behavior. • Log Scale: If Denoise SOR is selected, this setting emphasizes details in regions with lower point density and reduce the impact of regions with high point density. It allows the filter to treat points with different magnitudes more uniformly, enhancing the denoising process by effectively dealing with variations in the dataset.





Button	Action
	<ul style="list-style-type: none"> • nSigma: If Classic SOR is selected, this option will calculate the mean distance from every point to its neighboring points. The result is a normal distribution. You can use decimal values here. The lower the number you choose, the more points will be trimmed from your dataset. <i>Default setting: 1</i> • Point outlying: Choose whether the outlying points will be deleted or just selected. • Invert: Select or delete everything in the point cloud except for the statistical outlying points. <div style="border: 1px solid #007bff; border-radius: 10px; padding: 10px; margin-top: 10px; background-color: #e6f2ff;"> <p>i Not available when working with meshes.</p> </div>
	<p>Moving object filter: Removes points over 5 second intervals and keeps fixed points in the environment.</p> <p>Identifying moving objects within a point cloud is done by estimating statistical scores for points based on their temporal and spatial relationship to their neighborhood. These scores provide a quantitative measure of the likelihood that a point belongs to a moving object, enabling the Moving Object filter to differentiate between dynamic and static elements in the point cloud.</p> <p>Refer to the Moving Object Filtering section for more information.</p>
3D view menu	
	<p>Focus: Fits the point cloud to your screen.</p>
	<p>Front: Shows the front view of the point cloud.</p>
	<p>Top: Shows the top view of the point cloud.</p>
	<p>Right: Shows the view from the right of the point cloud.</p>
	<p>Left: Shows the view from the left of the point cloud.</p>



Button	Action
	Back: Shows the back view of the point cloud.
	Bottom: Shows the view from the bottom of the point cloud.
Measurement tools	
	Point measurement: Click anywhere in your point cloud to show coordinates for a single point. Click again to clear your selection.
	Line measurement: Select any two points to show the distance between them and the coordinates for each point. Click a third point to reset the tool and take another measurement.
	Angle measurement: Select three points to measure the angle between them. Shows coordinates for each point.




Button	Action
Undo / Redo	
	<p>The undo/redo actions are currently limited to the following actions:</p> <ul style="list-style-type: none"> • Translate • Rotate • Point size, point bias, point shape • Color scale selector • Colorization filter • Fill color • Scalar gradient, with associated Scalar Filter upper/lower limit and scalar range changes <div style="border: 1px solid red; padding: 10px; margin-top: 20px;"> <p> The undo and redo functions are not currently available for delete actions, DBD and SOR filters, so be careful when performing these actions. Further functionality will be explored in future releases.</p> </div>



4.7 Visualize Tab

You can use the **Visualize** tab to see which files you have loaded into Emesent Aura. This tab is divided into three sections: **Point clouds**, **GCPs**, and **Meshes**.





4.7.1 Supported File Types

The file type determines which section in the tab your file appears in.

- **Point clouds:** las, laz, e57, xyz, ply
- **GCPs:** constellation.yaml
- **Meshes:** ply






 PLY is a standard mesh file format, which also serves as a supported format for point cloud data. Currently, Emesent Aura does not offer the capability to generate PLY files; it only supports the loading of third-party generated mesh PLY files. Also, interaction for imported meshes is fairly limited. This will be improved in future releases.


Table 12 Options

Button	Name	Action
	Display	Shows the file the in viewport. You can display multiple files at the same time.
	Hide	Hides the file in the viewport.
	Remove	Removes the file from Emesent Aura.
	Focus	Allows you to focus on <i>this particular file</i> in the viewport.




4.7.2 Moving the Panel

To move the panel containing the **Visualize** tab, hover over the upper left or right portion (depending on where it is located) until you see the **Dock** icon.



Click and hold the **Dock** icon then drag the panel to the left or right until you see a blue border to indicate that the panel will dock at that location once released.



Alternatively, you can make the panel float anywhere on the screen.



5. Working with Point Clouds

5.1 Processing Profiles


A profile is a group of processing settings that allow you to optimize processing for specific environments and situations. Emesent Aura has several built-in profiles available for processing, georeferencing, merging, and colorization. These built-in profiles will give good results in most situations.

If the built-in profiles don't cater to your needs, Emesent Aura also allows you to create and save custom profiles.

5.1.1 Built-in Profiles

The following built-in profiles are available.



Workflow	Profiles
<p>Process</p>	<p>Standard: We recommend that you use this profile for most processing operations. Sometimes this profile won't give you an outcome that you are happy with. If your point cloud output includes ghosting, copies of objects, or overlapping objects, or if the trajectory file significantly diverges from known information about the actual trajectory (for example, where a dataset from a closed loop scan is processed and the trajectory file shows the start and end points are a significant distance apart), we recommend that you try one of the other three built-in profiles.</p> <p>The default georeferencing mode for this profile is set to None.</p> <p>Low Features: Use this profile for environments with relatively few geometric features. It includes adjustments to window size and iterations. This profile can improve point clouds from some environments, but it can also result in worse point clouds from others.</p> <div style="border: 1px solid #0070C0; border-radius: 10px; padding: 10px; margin: 10px 0;"> <p> Auto SLAM eliminates the need to switch to the "Low Features" profile in most scenarios.</p> </div> <p>More Iterations: This profile is designed for environments that are more challenging for the SLAM algorithm to handle. It increases the number of iterations.</p>
	<p>Forest: This profile is designed for environments that are largely or exclusively natural terrain and vegetation. It includes adjustments to the way that global registration is performed.</p> <p>ST-X: This profile contains the recommended intensity and range filtering settings as the ST-X LiDAR has a greater range and is more sensitive than older hardware.</p> <p>Disable Feature Matching: This profile is recommended when scanning featureless or repeating environments such as multi-story building car parks.</p>
<p>GCP</p>	<p>Standard: The default profile for a GCP workflow. This profile will cater to the most common georeferencing jobs.</p> <p>ST-X: This profile contains the recommended settings for detecting targets when georeferencing the point cloud.</p>



Workflow	Profiles
Merge	<p>Standard: The default profile for a merge process. This profile will cater to the most common merge jobs.</p> <p>Outdoor Indoor: This profile can give better results when merging datasets that have overlaps between outdoor and indoor environments.</p> <p>Complex Building: This profile can give better results when merging datasets from complex building structures, such as buildings with multiple levels or with multiple similar rooms.</p> <p>Terrain: This profile can produce better results when merging datasets from outdoor environments with large open areas.</p>
Colorization	<p>Standard: This default profile provides a set of configuration parameters that should suit most colorization requirements. It achieves a good balance of output quality vs processing time for most datasets.</p> <p>Quick: This profile delivers a faster output at the cost of quality. This option is useful when reviewing results in the field. Only one video frame every 5 seconds is used to colorize the points, which may result in gaps or poor colorization.</p> <p>Quality: This profile increases the quality of the colorized point cloud at the cost of increased processing time. It uses 10 frames every second (instead of two, which is standard), and decreases the visibility voxel scale from 250 mm to 100 mm.</p> <p>Driving: This profile is useful when colorizing scans done at higher speeds (for example, driving scans). It uses 10 frames per second (instead of two, which is standard) to ensure sufficient coverage at high speed.</p>
Extract 360 Images	<p>Telescopic mount extended: This profile provides orientation parameters for extracting images on a 360 camera captured with the telescopic mount fully extended.</p> <p>Telescopic mount retracted: This profile provides orientation parameters for extracting images on a 360 camera captured with the telescopic mount retracted.</p> <p>360-camera mount calibrated: This profile provides parameters for extracting images on a 360 camera captured with the calibrated 360-camera mount.</p>




5.1.2 Custom Profiles

When you make changes to a built-in processing profile in Emesent Aura, a temporary custom profile is created. You can choose to save this custom profile to save time in setting up processing jobs for common or known environments. Once saved, it becomes available for selection in the **Profiles** dropdown list.

i If you choose not to save the custom profile, it is automatically removed when the application is closed.

To create a new processing profile:

1. Go to the **Process** tab then click **Process Scan**.
2. Select the workflow to create a new profile for then click the **Add Profile** icon.
3. In the **Create Profile** dialog box, enter a name for the new profile then click **Create**.




4. Click **Processing Settings** then customize the settings for the new profile.
5. Click **Save**. Your new profile should now be available in the dropdown list.




To save a custom profile:


1. Go to the **Process** tab then click **Process Scan**.
2. Select a workflow then select from one of the available built-in profiles.



3. Click **Processing Settings** then edit the settings of the built-in profile.
4. Click **Save** to go back to the main panel. The selected profile changes to the newly created "Custom" profile.
5. Click **Save Profile**.



6. In the **Create Profile** dialog box, enter a name for the new profile then click **Create**. Your new profile should now be available in the dropdown list.





5.2 Output Folders

Point cloud processing (SLAM) involves a sequential series of stages, usually Odometry, Atlas, and Global.

These files are stored in the following folders:

Folder	Description
IntermediateFiles	Contains the intermediate results, which are not intended for direct user interaction. A subfolder is created for each processing stage (e.g., "offline_odom").
Output	Contains the final output artefacts associated with the processing workflow.



5.3 Cleaning your Point Cloud

Every user will clean their point clouds slightly differently. We recommend the following process.

5.3.1 Step 1: Copy your point cloud file

Start by making a copy of your original point cloud file. This will be the file you work on in Emesent Aura.

5.3.2 Step 2: Open in Emesent Aura

Open the copy file in Emesent Aura. You can do this in one of three ways:

- In the top-left menu, click the **Project Menu** icon then select **Open** in the menu that displays.
- Drag and drop your file directly into the viewport.
- Go to the **Visualize** tab then click **Add** next to your chosen section.

5.3.3 Step 3: Make your point cloud visible

To ensure you can easily see all points for cleaning purposes, we recommend doing the following.

1. Change the point cloud to a solid color:
 - a. Select the point cloud to display its Context panel.
 - b. In the **Color Scale** field, click **Solid**.
 - c. In the **Fill Color** section, choose a color for your point cloud that contrasts with sepia (which is the default selection color).
Note: When you change the color of the point cloud, the color of the bounding box automatically changes at the same time. This is useful if you have multiple point clouds open. It allows you to see the extent of each point cloud (assuming they are different colors).
2. Change the background color to a solid color:
 - a. In the top-left corner, click **Preferences**.
 - b. In the **Preferences** dialog box, go to the **Appearance** tab.
 - c. In the **Background** section, select **Solid**.
 - d. Choose a color that stands out against the point cloud color. We recommend that you avoid using a black background for clean-up, as it can make points easier to miss (especially if you are working with a colorized point cloud)




- e. Click **Save**.
3. Change your point size so that the points are easily seen:
 - a. Go to the point cloud panel.
 - b. In the **Point Size** field, set the value to **1** or greater.

5.3.4 Step 4: Start with a small area

We recommend that you clean only small areas of your point cloud at a time (particularly if you are cleaning using filters). If you clean the whole point cloud at once, you may accidentally remove features that you did not intend to, and there is currently no undo function for deletion.

1. Select a small area of your point cloud. If this area is on the edges of your point cloud, make sure that it includes at least a portion of the main point cloud, not just the peripheral points. The reason for this is so that Aura has a better idea of the mean distance between *all* the points, not just the peripheral ones. If you only select the points on the edges, this could skew your filtering.

 When you choose an area, a selection will be created that extends back through the point cloud. This means that your selection includes points that are behind your visible selection, which may not be your intention. If you have opted for perspective mode in your global preferences, the selection's shape will expand as it moves further into the distance. On the other hand, if you have chosen orthographic mode, the shape will remain the same throughout the point cloud.

2. To find points that may have been selected further into the distance, you can either:
 - Navigate to the other side of your point cloud to check that nothing else has been selected.
 - Use the near clipping plane, which will allow you to see through areas of your point cloud. To do this, go to the **Preferences** menu and change the value in the **Near Clipping Plane** field. Experiment with what works best for you.
3. Refine your selection as follows:
 - **To add points:** Shift + select
 - **To remove points:** Ctrl + select
 - **To invert your selection:** Alt + select



5.3.5 Step 5: Use the SOR filter

We recommend using the SOR filter for your first clean before you do your manual point removal. This is a good way to clean up the edges of your scan, where there is usually quite a bit of noise.

The SOR filter allows you to remove stray points and noise in a dense point cloud. This filter works out the average distance of each point from its neighboring points. It then rejects the points that are farther than the average distance. All points outside this distance are considered outliers and can be removed from the dataset. You may have to experiment with the settings to achieve the desired result.

i Automated filtering can be integrated into the processing workflow. To do this, go to **Processing Settings**. In the **Point Filtering** section of the **General** tab, enable the cleaning filter(s) to be automatically applied during processing.

i The bounding box, which shows the furthest extent of the points in your point cloud, does not automatically adjust when trimming points. Save the point cloud first then reload it to see the adjusted bounding box.

1. Once you have selected your area for cleaning, go to the **Main Toolbar**.

i If no selection is made, the filter is applied on the entire point cloud that is currently selected. The filter is disabled if multiple point clouds are selected in the **Visualize** tab.

2. Click the **Cleaning Filters** icon then select **SOR filter**.
3. In the **Statistical Outlier Removal** dialog box, select the SOR filter to use. Refer to the [Main Toolbar](#) section for more information on the different SOR filters and their associated settings.
4. Once you have configured the settings for the selected SOR filter, click **OK**.



5. Points selected for clean-up will change to a sepia color. If you are happy with the selection, proceed to delete these points.
6. Run the SOR filter in the same area until you are happy with the result.

i The DBD filter is not suitable for point cloud clean-up. It is more suitable for meshing, as you're effectively just subsampling the point cloud by running this filter. Currently, meshing is not supported within Emesent Aura.

5.3.6 Step 6: Do a manual clean-up

Once you have finished using the filters for your initial clean-up, you can then do a manual clean-up. Go to the [Main Toolbar](#) section for more information about each tool.

i The Selection Tools in the Main Toolbar work across multiple point clouds. If you have two point clouds selected at the same time, you can select points in both. To select/unselect multiple files, hold down the **Ctrl** key then click on each file you want to select or unselect.

5.3.7 Step 7: Save

From the **Project Menu**, click **Save** to save the changes to the existing file. Use **Save As** to create a copy of your point cloud with a different name, location, or file format.



5.4 Process Workflow

To create a point cloud from your raw Hovermap data, you need to process the scan in Emesent Aura.

i If you are planning to georeference your scan, you may skip this process as point cloud processing is also performed when using the GCP workflow. Refer to the [GCP Workflow](#) section for more information.

✓ Because of Aura's significant processing requirements for generating a point cloud from Hovermap data, we recommend your laptop is connected to a power outlet during Step 5: Processing.

The basic process for generating a point cloud is as follows.



5.4.1 Step 1: Retrieve your scan data

Follow the [Hovermap workflow](#) to capture your scan data. Once you have completed your scan, insert a USB flash drive into Hovermap to download the data. The status LEDs will change to a light flashing blue while the scan is being transferred.


i To retrieve data, the USB flash drive must be formatted in an exFAT file format.


Once the transfer is complete, the status LEDs will return to a slow pulsing Emesent blue. You can now remove the USB flash drive.



5.4.2 Step 2: Copy the data to your computer


Copy the data from the USB flash drive to a local drive on your computer so that you can begin processing.

 Scans from a Hovermap that use Emesent Cortex version 3.3 (or later) can only be processed in Aura 1.7 (or later).


 For scans from a Hovermap that use Emesent Cortex version 3.3 (or later), it is essential to ensure that both `metadata.yaml` and `platform_configuration.yaml` files are included in the same folder as your scan files. These files contain crucial information required for processing the point cloud data.

5.4.3 Step 3: Configure your processing job


1. Open Emesent Aura. Make sure you have an active **SLAM** license.
2. In the **Process** tab, click **Process Scan**.
3. In the **Configure New Scan Job** panel, select the **Process** workflow.
4. Click **Add Dataset**.
5. Browse for the folder that contains the raw point cloud dataset to be processed. Select that folder.




6. When prompted, select the **Scan Environment**. Choose the environment that **most closely** matches your scan.



- 7. In the **Location** field, enter the preferred name for the output folder. Emesent Aura will create this folder, which stores all the processed results and data, as a child directory within the raw scan folder.




- 7. Select the processing profile to use. Refer to the [Processing Profiles](#) section for more information about which profiles to use and how to create a custom profile.



5.4.4 Step 4: (Optional) Use RTK Data

1. If RTK data is detected in your dataset, toggle on **Use RTK data** to use the real-time corrections provided by the RTK system to improve the georeferencing accuracy of the point cloud data.


More information on processing and reprojecting a georeferenced scan is provided in [Reprojection](#) section.





5.4.5 Step 5: Processing

1. Click **Start** to begin processing. The **Configure New Scan Job** panel is replaced with the **Starting Processing Job** panel and shows a progress bar showing how far along you are in your processing job. In addition to the progress bar, the elapsed time of the processing job is shown to the right. The directory file path below the progress bar provides a way to identify the dataset source. This is useful if simultaneously processing multiple jobs with the same output folder name. Copying the file path and pasting it on your computer's file explorer allows you to access the completed files without having to wait for the processing job to be completed.



2. The processing job will proceed through the local and global processing phases and finally generate the output processing files. You can load and interact with other point clouds while processing in the background. Refer to the [Output Files](#) section for more information on where the generated files are stored once the processing is completed.

i The **Retry** button becomes available if a failure occurs during processing. Click this button to attempt to process the current job from the last successful stage.

3. The resulting point cloud is added to the child directory created within the raw scan folder.



5.4.6 Step 6: View your point cloud

- Once your processing job has finished, the bottom panel displays the generated files.



- Click **View** beside each generated file to load them into the Viewport for analysis or further editing. The following main files are generated:

- Full point cloud
The point cloud with the complete set of data points. The output file type varies depending on the profile used in generating the point cloud. The filename includes the output folder name with the output file type appended to it.
For example: *Output_laz1_4.laz* where the output file type is PointCloud LAZ (1.4) and the file is located in the "Output" folder.
- Subsampled point cloud
The point cloud containing a subset of points from the original point cloud dataset (based on **Subsample Factor** value in **Processing Settings**). This output is only generated if **Subsample Point Clouds** is enabled in the **Output** tab of the **Processing Settings** panel.
- Trajectory file
The data file containing the recorded movement or path of the Hovermap as it acquired the point cloud data.



5.5 GCP Workflow

The Emesent Knowledge Base article [Working with Point Clouds - GCP Workflow](#) walks you through the entire GCP workflow step-by-step, and links to the complementary video Best Practice for Automated Ground Control Points.

5.5.1 Processing Scan Data with Ground Control Points (GCPs)

This workflow outlines how to process scan data using Ground Control Points (GCPs) in Emesent Aura.

5.5.1.1 Aura Supports:

- **Automatic Match Targets:** Circular reflective targets that Aura can match automatically to the imported Survey Data.
- **User Selected Targets:** Other identifiable features such as checkerboards, paint marks, or natural landmarks that can be user assigned.
- **Check Points:** Surveyed points that are used for independent accuracy validation.

All surveyed points can contribute to georeferencing the point cloud, improving accuracy and reducing Simultaneous Localization and Mapping (SLAM) drift.

5.5.1.2 Requirements

The following are required to complete this workflow:

- **Software:** Aura 2.0 or later.
- **Scan data:** Hovermap scan data with visible targets.
- **Surveyed targets:** At least 3 GCPs (automatic or user-selected), with optional Check Points.
- **Survey Data:** Coordinate information for each GCP, including X (easting), Y (northing), Z (elevation), and the radius for automatically detected targets. Coordinates may be provided in metres or feet. Both US survey foot and international foot units are supported for import as part of the GCP workflow.



5.5.1.3 Procedure

Step 1: Format Survey Data

Prepare a CSV file containing the surveyed coordinates for each GCP target visible in the scan. Coordinates can be surveyed **before or after scanning**, but they must be available **before processing in Aura** to enable georeferencing and improve SLAM accuracy using GCPs. Use a suitable survey instrument such as a GNSS receiver or total station.

1. Create a new **CSV (Comma Separated Values)** file, or download this **template**.



Save the file as **CSV (Comma Separated Values)** only, not **CSV UTF-8**, or Aura may fail to import it.

2. Enter one line per GCP target using the following structure: `ID, X, Y, Z, Radius`


Column	Description
ID	Unique identifier for the GCP.
X	Easting coordinate.
Y	Northing coordinate.
Z	Elevation. Use a right-handed coordinate system with Z (elevation) defined as up.
Radius	Target radius in meters. Enter the radius only for flat, circular retro-reflective targets. Leave this field blank for all other target types. Aura only attempts automatic matching when a radius is provided. For Emesent-supplied reflective targets, use 0.125 m for small targets (25 cm diameter) and 0.250 m for large targets (50 cm diameter) .

Example


```
ID,X,Y,Z,Radius
Reflective_big_1,2736.075,5595.273,27.596,0.250
Paintmark1,1326.747,5388.476,22.041,
Reflective_small_1,1309.543,5141.822,29.607,0.125
```



```
Reflective_small_2,1787.757,5270.110,21.275,0.125
Checkerboard1,1818.227,5731.992,28.501,
Checkerboard2,2774.159,5115.728,29.817,
```

 Imperial coordinates are **not supported**. All coordinate values must be in **unscaled metres** before import into Aura. Control points must **not** be stored in a coordinate reference system that applies **scaling** (such as **UTM**).

1. Finalize the CSV file
 - **Verify column count:** Each row must contain exactly 5 columns. Entries with a user-selected target must contain exactly 4 columns.
 - **Filter entries:** Include only the surveyed GCPs that were visible in the scan.
 - **Save format:** Save the file with a .csv extension.
 - **Close file:** After saving, close the file. Leaving it open in Excel may cause issues when importing into Aura.


 For easier organization and to avoid errors, it is recommended to store the **Survey Data CSV** in the same folder as the dataset.

Step 2: Open Emesent Aura

1. Open **Aura** by double-clicking the desktop icon or launching it from the **Windows Start menu**.

Step 3: Select processing type

1. In the **Process** tab, click **+ Process Scan** in the upper-left corner of the interface.
2. In the **Configure New Scan Job** panel at the bottom of the screen, select **GCP** as the scan type.





Step 4: Add scan and Survey Data

1. In the **Configure New Scan Job** panel, click **Add Dataset** to open the **Add GCP Data** dialog box.
2. In the **Add GCP Survey Data** popup, add both the dataset folder and the Survey Data CSV.
 - **Add dataset folder:** Browse to the root folder of the unprocessed scan. Do not select subfolders such as **Output/**. Always choose the root folder of the extracted scan.
 - When prompted, select the **Scan Environment**. Choose the environment that **most closely** matches your scan.
 - **Add Survey Data:** Select the **CSV file** created in **Step 1**.
 - Select the unit of measurement your Survey Data Csv is in.

UNIT OF MEASUREMENT

Choose the unit of measurement your csv data is in.

Meters

US Survey Foot

International Foot

NEXT CANCEL

i If you have not yet generated the CSV file, or if the file fails validation, click **Download .csv template** in the Aura interface to obtain a new template.



ADD GCP SURVEY DATA

Add the dataset folder and survey data (.csv file) that you would like to georeference.

Add dataset folder: ADD No dataset selected

Add survey data: + IMPORT CSV No survey data selected

[Download .csv template](#)

Please ensure the survey data:

- contains only the target ID, X, Y, Z, and target radius
- has the radius field blank if you are not using flat, circular retro-reflective targets for auto detection
- is in ground coordinates, as SLAM uses a scale factor of 1.000000. Using grid coordinates may create distortion.

<input type="checkbox"/>	ID	X (Easting)	Y (Northing)	Z (Elevation)	Radius (m)
--------------------------	----	-------------	--------------	---------------	------------

BACK
SAVE
CANCEL

i Loading an unprocessed dataset into Aura may take time, as Aura validates the dataset based on the scan size.

Step 5: Review loaded Survey Data

Aura will display the **CSV file** in the **Add GCP Survey Data** popup once it has been loaded.

1. Review the data to ensure it is correct and that the correct file has been selected.
2. Choose one of the following options:
 - **Save** – click **Save** to proceed with processing.
 - **Change CSV** – click **Change CSV** to select a different Survey Data file.



ADD GCP SURVEY DATA

Add the dataset folder and survey data (.csv file) that you would like to georeference.

Add dataset folder:

CHANGE DATASET
✕

Example GCP Scan

Add survey data:

CHANGE CSV
✕

Survey Data.csv

[Download .csv template](#)

Please ensure the survey data:

- contains only the target ID, X, Y, Z, and target radius
- has the radius field blank if you are not using flat, circular retro-reflective targets for auto detection
- is in ground coordinates, as SLAM uses a scale factor of 1.000000. Using grid coordinates may create distortion.

<input checked="" type="checkbox"/>	ID	X (Easting)	Y (Northing)	Z (Elevation)	Radius (m)
<input checked="" type="checkbox"/>	Reflective_big_1	1993.884	5461.774	22.204	0.25
<input checked="" type="checkbox"/>	Reflective_big_2	2029.313	5461.567	22.141	0.25
<input checked="" type="checkbox"/>	Reflective_big_3	2056.052	5458.877	22.036	0.25
<input checked="" type="checkbox"/>	Paintmark1	1996.465	5448.318	21.948	
<input checked="" type="checkbox"/>	Paintmark2	2062.89	5448.334	21.958	


BACK
SAVE
CANCEL

Step 6: Define output location

1. In the **Configure New Scan Job** panel, locate the **Location** section at the bottom of the screen.
2. In the text box beside the **Location** scan folder path, enter a descriptive name for the output folder.
3. Verify that both the location and the folder name are correct before continuing.




If no name is entered, **Aura** creates a **subfolder** named `output` by default.



Step 7: Select processing profiles

1. In the **Configure New Scan Job** panel, select a processing profile for **SLAM** and a processing profile for **GCP**.
 - The **SLAM profile** controls how SLAM data is processed.
 - The **GCP profile** controls the settings applied to GCP processing.
 - For most scenarios, select **Standard**.

i On addition of a dataset, profiles may be automatically set based on the hardware used to capture the scan.






⚠ If the processed output shows ghosting, misalignment, or duplicated features, select an alternate **SLAM profile**. If Aura does not automatically detect the expected targets or meet accuracy requirements, select an alternate **GCP profile**. These profiles affect SLAM and GCP settings, respectively, and should be chosen to suit the scanning environment and mission requirements.


Step 8: (Optional) Customize processing settings

Aura provides several processing settings that can be adjusted when the default profiles are not suitable for the scanning environment or project requirements. These settings are grouped into three tabs: **General**, **GCP**, and **Output**.

1. In the **Configure New Scan Job** panel, click **Processing Settings** in the lower-left corner.



2. Adjust the **General** and **Output** tabs as needed, using the same options as standard scan processing.



3. Open the **GCP** tab to refine how targets are detected and processed. See the *GCP settings reference* below for details on each option.
4. Click **Save** to apply changes.

⚠ For scans with partial or no **Automatic Match Targets**, ensure **Wait for GCP Target Manual Review** remains enabled (default setting). If disabled, Aura will skip the manual step and process the point cloud without GCP correction.

GCP settings

The settings below primarily affect how compatible targets are automatically matched. However, target position uncertainty can also impact the accuracy of the processed, georeferenced point cloud.



Option	Description	Use Case
Intensity	The expected range of intensity values of the retro-reflective targets. ST-X: 250–255 ST/ HVM100: 150–255	Use when Automatic Match Targets are not being detected as expected. Narrow or widen the range until reflective targets appear within the detection band. Adjust the band based on the reflectivity of your targets. Widening the band allows Aura to identify more targets but may also pick up additional reflective objects such as bollards, signs, or vehicle mirrors.
Number of points	The minimum number of points required to detect a target.	Use when auto-detection of targets is inconsistent. Increase the value when false positives are being created in dense scans, as requiring more points reduces the chance of random clutter being flagged as a target. Decrease the value when targets are small or only partially scanned, as this ensures Aura can still identify them with fewer points. Keep in mind that increasing the value will cause sparsely scanned targets to be missed, while decreasing the value will increase the number of false positives. The default value is 25 .
Point cloud target noise	The expected noise or thickness of the LiDAR points on the target.	Use when targets appear noisy or when clusters of points around a target are unusually thick. Increase the value if targets are not being detected due to excessive noise or if reflective surfaces appear fuzzy in the scan. Decreasing the value makes detection stricter, which can prevent misidentifying clutter as targets. The default value is 0.02 m (20 mm) .
Target position uncertainty	The uncertainty in the position of the surveyed targets.	Use when SLAM alignment appears over-constrained to the control points or when survey accuracy is uncertain. Increase the value to give Aura more flexibility when fitting the point cloud to Survey Data — for example, if control points have lower confidence or if overfitting causes distortions in the cloud. Decrease the value when survey control points are highly accurate and should strongly constrain the SLAM alignment. The default value is 0.003 m (3 mm) .



Step 9: Start processing


1. Click **Start** in the **Configure New Scan Job** panel to begin processing.



The **Configure New Scan Job** panel will be replaced with the **Processing Scan with GCPS** panel.

From here you can:


- Monitor the **progress bar** and **elapsed time** during processing.
- Click **Retry** if processing fails, to restart from the last successful stage.



Step 10: Open Constellation Matching

During processing, Aura will automatically detect clusters of points in the scan that resemble circular GCP targets, where a **radius** has been defined in the Survey Data. If **Review GCP** is enabled, Aura will then prompt you to review the detected GCP targets.

1. Click **Load Constellation** to open the intermediate point cloud and the associated constellation file.
2. (Optional) Once the constellation is loaded, you can click **Reload Constellation** to clear any user changes.




Step 11: Adjust display properties (optional)


To assist in identifying GCP targets in the point cloud, adjust the **Color Scale**. **Intensity** is the most effective option, but other scales such as **Time** or **Elevation** can also help narrow point selection.

<p>Example workflow</p> <ol style="list-style-type: none"> 1. Change the Color Scale to Intensity to highlight reflective targets. 2. Adjust the visibility of points in the scalar filter to display only highly reflective points. This makes GCP targets easier to locate. 3. Adjust the scale of the color gradient in the scalar filter to highlight details. Use alternative Color Scale gradients to help identify targets with variable reflectivity. <p>Scalar Filter controls</p> <ul style="list-style-type: none"> • Adjust the visibility of points: Drag and drop the blue dots along the bottom to set which points in the scale are visible. • Adjust the scale of the color gradient: Drag and drop the colored square boxes along the top to define which points in the scale correspond to which colors. 	
---	--

Example: Filtering highly reflective targets using the Intensity Color Scale



Example: Displaying variable reflectivity targets using the Color Scale gradient



Step 12: Match survey points to targets



In this step, you will link the survey points from the CSV file to their corresponding targets in the point cloud. This establishes the relationship between the surveyed coordinates and the detected features in the scan, which is critical for accurate georeferencing.

If **Automatic Match Targets** were detected, these will already be assigned. Use this step to confirm the matches and make manual corrections if required.

Navigating to and hiding targets

These options can be used to focus on individual targets when reviewing or correcting assignments.









	<p>Centre target: In the Survey Points list, click the center icon to automatically center the viewport on that location.</p>
	<p>Show or hide target: In the Survey Points list, click the eye icon to hide or display the target in the point cloud.</p>

GCP settings

Errors shown below are for the current rigidly aligned point cloud and will be reduced in the final SLAM process.

+ ADD TARGET
EDIT TARGET
RE-ALIGN

	Point	Type ?	Target
<input type="checkbox"/>	  Reflective_big_1	Control ∨	 target_1 ×
<input type="checkbox"/>	  Reflective_big_2	Control ∨	 target_2 ×

There are two methods for assigning user-selected targets.


Recommended method: Manual selection

1. In the **Survey Points list**, select the survey point you want to associate with the target using the checkbox, then click **Add Target**. This will automatically open the **Select Point tool**.
2. Use the **Select Point tool** to left-click near the center of the target in the point cloud.
3. **Refine placement** using the keyboard arrow keys.
4. Click **Confirm** when the target location is correct.



- Repeat the process until at least 3 survey points are assigned.
Then click **Re-Align** to align the point cloud with the survey data, making it easier to locate and match the remaining points.

i **Re-Align** also updates the rigid alignment error. Reviewing this value can help identify issues such as incorrect point assignment, mismatched targets, or errors in the CSV coordinates.



Alternative method: Auto-select from filtered points

- Adjust the visibility of points** so that only the desired target points remain visible.
- Use the **Select tool** to highlight the group of points containing the target.
- In the **Survey Points list**, select the survey point you want to associate with the target using the checkbox.
- Click **Add Target**. Aura automatically places the target at the center of the selected points.
- Refine placement** with the keyboard arrow keys.
- Click **Confirm** when the target location is correct.



Step 13: Complete target assignment

1. Continue assigning the remaining survey points to their corresponding targets in the point cloud.
2. Check the target status in the **Survey Points** list:
 - **Green box** – the target has been successfully associated with a survey point.
 - **Blue box** – the target is not associated with a survey point and may need review or deletion.



3. Review the list of **inactive targets**. These are targets that were not successfully matched to a survey point, or that may have been mismatched to an invalid location. Inactive targets do not contribute to georeferencing or alignment until they are reassigned.



- If valid, **drag and drop** an inactive target into the **Survey Points** list to associate it with the Survey Data.
- **Delete** the target if it is not valid.
- **Leave unused** if the target is not required for georeferencing.

Inactive targets

Drag and drop the inactive targets to the correct control points in table above to assign the target.

👁 target_0 ✕

👁 target_5 ✕

👁 target_6 ✕

👁 target_7 ✕

- (Optional) Mark survey points as **Check Points** if they should be used only for accuracy validation and not for correcting the scan.

	Point	Type ?	Target
<input type="checkbox"/>	👁 📍 Reflective_big_1	Control ^	👁 target_1 ✕
<input type="checkbox"/>	👁 📍 Reflective_big_2	Check	👁 target_2 ✕
<input type="checkbox"/>	👁 📍 Reflective_big_3	Control	👁 target_3 ✕
<input type="checkbox"/>	👁 📍 Paintmark1	Control v	⚠ Not assigned

- Review the pre-SLAM rigid alignment error to confirm accuracy and identify any mismatches.

Average error	0.005
RMS error	0.006




i The reported error values may be large, especially in large or challenging SLAM environments. These values are expected to reduce once SLAM correction is applied during processing.


Step 14: Complete GCP review

This step finalizes georeferencing by applying the constellation alignment to correct drift and complete the scan.

1. Confirm all required targets are matched to survey points. Matched points are indicated by a green box and label text.




2. Click **Confirm**. Aura will then process the scan again with GCPs applied to correct drift.





Step 15: View the final output

Once Aura has completed processing, the **Processing with GCPs** panel is replaced with the **Processing with GCPs Complete** panel. From this panel you can access the processed output.



1. Review the final output by either:
 - Opening the files manually from File Explorer, or
 - Using the **View** function in the **Processing with GCPs Complete** panel.

Panel options

- **Open Folder:** Opens the scan directory in File Explorer. Inside, you will find the **Output** folder, or your custom-named folder, containing the processed data.
- **Files list:** Each output file includes a **View** option. Clicking this will open the file in Aura or in the system's default external program (e.g. PDF viewer or spreadsheet application).

File	Description
Processed point cloud	Full-resolution point cloud generated from the processed scan.
Subsampled point cloud	Reduced-resolution version of the processed point cloud.
Scan trajectory	Trajectory data of the scan path.



File	Description
CSV accuracy report	<p>Accuracy report in .csv format, named after the scan with date/time of processing.</p> <p>The accuracy report describes the correlation between ground control points (GCPs) and point cloud data. Each GCP is positioned within the point cloud data, and determines the error in X, Y, and Z. The average error of the individual control points is calculated as a Root Mean Square (RMS).</p>
PDF accuracy report	Accuracy report in .pdf format, named after the scan with date/time of processing.

5.5.2 Check Points

5.5.2.1 What are Check Points?

Check Points are **surveyed reference points** used only for **validation**. In surveying and mapping practice they may also be called **check measurements**, **check stations**, or **independent validation points**. Unlike **control points**, which influence the dataset during **georeferencing** or **adjustment**, Check Points remain outside the correction process. Their purpose is to provide an **unbiased measure of accuracy**, giving assurance that deliverables meet **project specifications** or **regulatory standards**.

5.5.2.2 How Check Points work in Aura

During the **Ground Control Point (GCP) workflow**, Check Points can be included in the same **CSV file** as control points. When assigning targets, selected points can be **marked as Check Points** to exclude them from **SLAM correction** and **georeferencing correction**.

Aura compares the **coordinates** of the Check Points with the corresponding coordinates derived from the **point cloud target locations**. The **differences (residuals)** between the reference coordinates and the point cloud coordinates are calculated and reported in the **GCP accuracy report**. This **independent dataset** confirms the accuracy of the processed point cloud without influencing the correction process.

5.5.2.3 Using Check Points helps you:

- Verify **scan accuracy** after georeferencing.



- Provide documented **quality assurance** for deliverables.
- Demonstrate compliance with **industry standards** that require independent accuracy checks.
- Increase confidence in **Simultaneous Localization and Mapping (SLAM)** results.\

i Not every **surveyed point** should be used for georeferencing. Reserving some points as **Check Points** ensures that an **independent dataset** is available for **validation**, rather than allowing all points to influence SLAM correction or georeferencing correction.

5.5.2.4 How Check Points are used

Check Points are included in the same survey CSV file as control points. During the **Georeferencing with Ground Control Points (GCPs) workflow**, you can nominate individual targets as Check Points. These points are excluded from correction and used only for accuracy validation.

For detailed instructions, see the [Georeferencing with Ground Control Points \(GCPs\) workflow](#) in the Knowledge Base.

5.5.2.5 Accuracy reporting with Check Points

When you include Check Points in your survey CSV and assign them during the GCP workflow, Aura calculates their positional difference against the processed point cloud. These residuals are summarized in the accuracy report alongside control point results.

The report includes:

- **Check Point summary:** Average and Root Mean Square (RMS) error values across all Check Points, showing how closely the processed point cloud matches surveyed ground-truth coordinates.
- **Per-point residuals:** Pre-SLAM alignment errors and final errors (X, Y, Z, and 3D) for each Check Point.
- **Control Point summary:** Accuracy results for the points used in georeferencing, shown separately for comparison.

Check Points influence reporting by providing:

- **Independent validation:** Residuals provide an unbiased measure of scan accuracy.
- **Context for deliverables:** Accuracy evidence for stakeholders and clients.



- **Early error detection:** Large residuals can flag survey mistakes, target misassignments, or SLAM drift.
- **Quality assurance:** Supports compliance with industry standards and builds confidence in results.

5.5.2.6 FAQ

What are Check Points?

Check Points are surveyed points with known coordinates that are excluded from SLAM correction and georeferencing correction. They are used to validate accuracy after processing by comparing the surveyed positions with the processed dataset. In Aura, these comparisons are reported as residual errors in the accuracy report.

Why use Check Points?

- Meet surveying and geospatial standards that recommend or require independent accuracy checks.
- Provide documented proof that your scan meets project tolerances (for example, ± 20 mm).
- Ensure validation is independent of the control points that influence georeferencing.
- Avoid the need for third-party software or additional workflows to validate accuracy.

Can I use Check Points with control points in the same CSV?

Yes. Both control points and Check Points can be included in the same CSV file. Mark points as Check Points during assignment.

Are Check Points included in georeferencing corrections?

No. Check Points are excluded from the correction process and contribute only to validation and reporting.

How many Check Points should I use?

A minimum of 3–5 well-distributed Check Points is recommended for reliable validation. More may be required for large or complex projects.



Why not use all surveyed points as control points?

Using every surveyed point for georeferencing would remove the independent dataset needed for validation. By keeping some points as Check Points, you maintain an unbiased measure of accuracy rather than letting all points influence the correction.

What is the difference between "Before GCP correction rigid alignment error" and the "Final error"?

The Before GCP correction rigid alignment error is reported after survey points are assigned but before SLAM correction is applied. It shows the initial fit between the SLAM trajectory and the survey data and may appear large in complex or extended scans.

5.6 Merge Workflow

Aura's Merge workflow uses a SLAM-based algorithm to non-rigidly align multiple datasets into a single, seamless point cloud output. Merging multiple point clouds improves efficiency, accuracy, and usability especially for complex, multi-scan projects. It also ensures consistent alignment of scan data, resulting in a high-quality deliverable.

Aura supports merging a combination of georeferenced and non-georeferenced scans. Each scan must be individually processed before merging.

The merge process outputs individual `.laz` files for each scan. These files are aligned using the SLAM algorithm and georeferenced if applicable. The individual `.laz` files can then be combined within Aura to produce a unified point cloud.

The following steps outline the merge workflow in Aura.



5.6.1 Prepare for the Merge

5.6.1.1 Ensure Overlap

During capture, ensure there is adequate overlap between scans. We recommend approximately 20% overlap to provide sufficient information for accurate alignment.

i You can merge vehicle RTK, backpack RTK, and non-RTK scans together. RTK scans will help improve the alignment of non-RTK scans in areas where they overlap.

5.6.1.2 Consider System Resources

Although there is no strict limit to the number of files you can align, processing demand will increase with each added dataset. Avoid merging point cloud files that add up to more than your available RAM. Use subsampled point clouds to reduce computational load.

5.6.1.3 Scan Requirements for Merging

Before merging, each scan must be processed in Aura:

- **Georeferenced Scans (RTK):**
 - Must be processed with the correct device under **Georeferencing mode** in **Processing Settings**.
 - **Set the base coordinate reference system** to match the **coordinate system used for RTK corrections**.
 - **Georeferencing** must be **Enabled** in Processing Settings.
- **Non-georeferenced scans:**
 - Must have **Georeferencing mode** set to **None** in the Processing Settings.
- **Drone RTK and GCP scans:**
 - Can be merged, but **georeferencing will not be retained**. Set georeferencing to **None** before merging.
- **Scans processed in Aura versions earlier than 1.10:**




- May default to **GPS** for non-georeferenced scans. Reprocess these scans in Aura 1.10 or later with georeferencing set to **None**.
- **Mixed scanner models:**
 - Merging scans captured using different Hovermap models (e.g. ST and ST-X) is supported, but ensure compatible firmware and Aura versions were used.



5.6.2 Merging Scan Data

5.6.2.1 Step 1. Configure Your Merge Job

1. **Open** Emesent Aura and **click Process Scan** in the top-left corner.




2. **Select** the **Merge** workflow in the **Configure New Scan Job** panel.



3. **Click Add Datasets**, then **click Add** next to *Add dataset folder*. (e.g. ScanJob123)





4. When prompted, select the **Scan Environment**. Choose the environment that **most closely** matches your scan.



SCAN ENVIRONMENT

*Select the environment that most closely aligns with your scan for optimized processing settings and output results:

Building and infrastructure

- Building interior
- Building exterior
- Bridge
- Road
- Tunnel / Sewer / Culvert


- Facility
- Forestry / Vegetation
- Greenfield

Mining


- Surface mining
- Access & transport drives
- Production voids
- Vertical infrastructure

- Waterway / Coastline

5. **Wait** for Aura to automatically detect and list the available files.



5. Repeat steps 3 and 4 for each additional scan you want to include in the merge.





5.6.2.2 Step 2: Choose an Alignment Base for Preview

For all merge types (Non-georeferenced scans, RTK, RTK + Non-RTK):

- In the **Alignment Preview File** column, select any scan to use as the alignment base.
- This file is used for preview purposes only and does not affect the final output. If available, Aura will default to a subsampled version.

ADD POINT CLOUDS TO MERGE

Please add the point clouds you would like to merge. Please ensure all point clouds have been pre-processed in Aura.

Add dataset folder ADD

Scan Folder	Alignment Preview File	Details	Action	Reference
Main Jetty	Main Jetty_subsampled_laz1_4.laz Output - (Processed Scan) ^	● Point cloud successfully staged for merge		<input type="checkbox"/> ⊖
Main Jetty 2	<div style="border: 1px solid #ccc; background-color: #444; padding: 2px; margin-bottom: 2px;">Main Jetty_laz1_4.laz Output - (Processed Scan)</div> <div style="border: 1px solid #ccc; background-color: #444; padding: 2px;">Main Jetty_subsampled_laz1_4.laz Output - (Processed Scan) v</div>	● Point cloud successfully staged for merge		<input type="checkbox"/> ⊖

SAVE
CANCEL



5.6.2.3 Step 3: Configure Apply Overrides (Optional)

For all merge types (Non-georeferenced scans, RTK, RTK + Non-RTK):

- Configure scan-specific settings, such as defining **exclusion zones** or **trim data**.

For RTK Merges and RTK + Non-RTK Merges:

1. Verify that RTK scans have their **georeferencing method** and **GNSS receiver type** correctly assigned. Aura will apply these automatically.

DATASET SETTINGS
GREBKHOLOVL_01

Enabling a section in this settings modal will override the settings provided by the currently selected profile.

Apply settings from an existing SLAM processing profile ?

Standard ▼ APPLY

Exclusion zones

Trim data

Georeferencing

If you require a custom projection, please select this projection in the merge profile settings.

Georeferencing mode Backpack RTK ▼

GNSS receiver type Emlid RS2/2+/3 ▼

Advanced ▼

SAVE CANCEL



5.6.2.4 Step 4: Select a Reference Scan (Optional)

For Non-georeferenced scans (Non-RTK) Merges:

- You can choose one scan to act as the reference scan. This scan will be locked in place, and all other scans will align to it.



If a reference scan is **not selected**, Aura will perform **pairwise alignment** between all point clouds. This increases computational complexity and may extend processing time.

For RTK Merges and RTK + Non-RTK Merges:

- Reference scans are supported for merges involving RTK scans. **Proceed to Step 5.**




5.6.2.5 Step 5: Configure Processing Settings

For all merge types (Non-georeferenced scans, RTK, RTK + Non-RTK):

1. **Define** the location and name for the merged output.



1. Adjust any desired settings using the general merge or output options, as outlined in the ***Aura User Manual, Section 3.3 – Process Tab.***



For RTK Merges and RTK + Non-RTK Merges:

1. Set processing settings:
 - a. Set the **Base Coordinate Reference System** to match the original horizontal CRS used during scan acquisition (e.g. EPSG:4326 – WGS 84).
 - b. To manually enter a full PROJ string, enable **Custom base CRS**.
 - c. Enable **Reprojection** (optional) if you want to transform the output into a different coordinate system. Define the **Target Coordinate Reference System** by selecting the desired horizontal and vertical CRS values.



Base coordinate reference system ?

Horizontal

Custom base coordinate reference system

Please use the entire proj string to set the base CRS

Reprojection

Target coordinate reference system ?

Horizontal

Vertical

Custom target coordinate reference system ?

Please use the entire proj string to set the target CRS



5.6.2.6 Step 6: Proceed to Alignment

For Non-georeferenced scans (Non-RTK) Merges:

- Proceed to **Step 7: Review and Manually Align**.

For RTK Merges and RTK + Non-RTK Merges:

- Proceed to **Step 7: Review and Manually Align**.

For RTK Merges

- If setup is correct, Aura will notify you that no manual alignment is necessary and you can skip manual alignment and start processing.



Alignment can be skipped and is optional as all point clouds are georeferenced, or load point clouds to align manually. Manual alignment preview loads non-georeferenced clouds and then georeferences them during processing.



5.6.2.7 Step 7. Review and Manually Align (If Required)

Aura's SLAM algorithm relies on overlapping features between scans to perform a merge. When georeferencing is unavailable or inconsistent across datasets, manual alignment is required to provide an initial position estimate. This reduces drift and improves the overall quality of the merged point cloud.




Manual alignment is required in the following scenarios:

- Merging scans without georeferencing (e.g. Non-RTK)
- Merging georeferenced and non-georeferenced scans together (e.g. RTK + Non-RTK)




Aura will attempt to merge scans even if they are misaligned, either horizontally or vertically. This can result in a skewed or inaccurate final output. Always verify alignment before continuing.

1. **Click Load Scans** to load all selected point clouds into the viewer.
 - Each scan is automatically assigned a unique color to assist with differentiation and alignment.
 - To add or remove datasets from the current merge job you can click **Edit Point Clouds Selected**.



2. **Align scans manually** using the **Translate** and **Rotate** tools. Start with **Top View** to position and rotate scans horizontally, then switch to **Front View** to adjust them vertically.






Figure 4 **Align horizontally using the Translate and Rotate tools.**




Figure 5 **Align Vertically using Translate**




Click Reload Scans in the **Configure New Scan Job** panel to reset a scan's position.



You are now ready to begin processing.

1. Click **Start** to begin the merge.



Start button not visible

If the **Start** button is hidden, click the **Configure New Scan Job** panel at the bottom of the window to reopen the **Processing Scan** panel and access the **Start** button.




5.6.2.8 Step 9. View and Combine Your Datasets


Once processing is complete, Aura outputs a `.laz` file for each scan. These files are stored in the directory specified in Step 1. They are aligned using the SLAM algorithm and georeferenced, if applicable.

You can now combine these individual `.laz` files within Aura to produce a unified point cloud. The outputs are grouped and displayed in the **Merge Complete** panel.


1. **Click View** under the **Merge Complete** panel to inspect each output dataset individually.




2. **Minimise** the **Merge Complete** panel to access the **Visualize** tab.



3. **(Optional) Adjust** the color of each point cloud in the **Visualize** tab to compare and validate the alignment and quality of the merged scans.
4. **Select** multiple datasets by holding **Shift** and **clicking** on each desired dataset.




5. **Open** the **Project** menu and **select Save As** to save the combined dataset as a single point cloud.



To combine datasets at a later time:

1. **Navigate** to the **Visualize** tab.
2. **Click Add** to load previously processed `.laz` files.



3. **Repeat** steps 3–5 above to compare, validate, and save the combined dataset.






5.6.2.9 (RTK Only) View the Combined Accuracy Report

After processing an RTK merge, each scan generates a `.csv` accuracy report. These reports are stored in the output folder of each individual scan. To load multiple reports into Aura and generate a combined accuracy report, follow the steps below.

1. **Open the Merge Complete** menu in Aura.
 - This appears automatically after processing, or can be accessed by clicking the **Merge Complete** bar.



2. **Click View** on the right-hand side of any `metrics.csv` accuracy report to open it.



MERGE COMPLETE

Output 100% PROCESSING COMPLETED 00:39:06


File path location: C:/My Scans/Bridge_merge/Vehicle_RTK_01/Output

OPEN FOLDER CLOSE

Files

File Name	Size	Action
Backpack_RTK_01		
Backpack_RTK_01_laz1_4.laz	778.77 MB	VIEW
Backpack_RTK_01_subsampled_laz1_4.laz	103.03 MB	VIEW
Backpack_RTK_01_traj_projected.xyz	24.66 MB	VIEW
Backpack_RTK_01_traj.xyz	24.83 MB	VIEW
Backpack_RTK_01_fit_metrics.csv	1.57 MB	VIEW
Handheld_01		
Handheld_01_laz1_4.laz	787.56 MB	VIEW
Handheld_01_subsampled_laz1_4.laz	103.18 MB	VIEW
Handheld_01_traj_projected.xyz	12.74 MB	VIEW
Handheld_01_traj.xyz	12.66 MB	VIEW
Vehicle_RTK_01		
Vehicle_RTK_01_laz1_4.laz	886.77 MB	VIEW
Vehicle_RTK_01_subsampled_laz1_4.laz	119.58 MB	VIEW
Vehicle_RTK_01_traj_projected.xyz	24.86 MB	VIEW
Vehicle_RTK_01_traj.xyz	24.95 MB	VIEW
merge_global_georeferenced_Handheld_01_fit_metrics.csv	252 Bytes	VIEW
Vehicle_RTK_01_fit_metrics.csv	785.72 kB	VIEW

3. **Click + CSV** in the report window to open Windows Explorer, then **navigate** to and **select** any additional `.csv` accuracy reports to include.



4. **Select the Combined Report** tab to view the merged accuracy data.



RTK ACCURACY REPORT

< **COMBINED** VEHICLE_RTK_01 × BACKPACK_RTK_01 × >

GPS data ?

No GPS	3D GPS	DGPS	RTK float	RTK fix
0%	0%	0%	9.52%	90.48%

RTK quality ?

	Horizontal (m)	Vertical (m)
RMS	0.02212	0.02699
50%	0.01414	0.01600
90%	0.02062	0.02900
99%	0.08853	0.11000

RTK → SLAM distance ?

	Horizontal (m)	Vertical (m)
RMS	0.06270	0.03660
50%	0.01794	0.01406
90%	0.04685	0.04447
99%	0.33724	0.15583

+ ADD CSVCLOSE



5.6.2.10 Colorize and/or Extract 360 images (Optional)

After merging, you can colorize your point clouds using camera imagery by following the instructions in the **Aura User Manual - Colorization Workflow**.

Merge Compatibility Summary

Scan Type	Merge Supported	Georeferencing Retained After Merge
Vehicle and Backpack RTK	✓	✓
Drone RTK	✓	✗
GCP	✓	✗

Troubleshooting

Issue	Cause	Solution
Merged RTK scans aren't georeferenced	Apply Overrides wasn't used	Select a georeferencing mode using Apply Overrides before merging scans.
RTK scans still require manual alignment	Georeferenced scan not set as the preview file	Select the RTK scan as the Alignment Preview File (satellite icon).
Aura isn't detecting my scan files	Wrong folder selected or scans not processed	Select the offload folder with <code>.bag</code> files, not the Output folder

5.7 Colorization Workflow

Emesent's colorization feature adds true color to your point clouds by combining Emesent LiDAR data with video captured from a supported camera. This provides clearer visual context and makes it easier to understand and interpret your scans.



5.7.1 Before Starting

Ensure your scan was captured with camera footage recorded during the mission using a supported, calibrated and correctly configured camera. The video files associated with the scan should be stored in the corresponding scan folder to keep the data correctly paired.

Colorization in Aura is applied to the LAZ file produced by supported processing workflows. It cannot run on raw scan data. Before proceeding, ensure the raw scan has been processed using the appropriate workflow such as SLAM, RTK or GCP. If your project involves merged scans, note that these require a [slightly different processing workflow](#).

Please review the resources below and ensure all items are complete before starting the colorization workflow in Aura.


- Camera and Hovermap were set up correctly following the [Colorization guidelines](#).
- The scan has been pre processed successfully using the appropriate processing workflow.
 - [Process Workflow](#)
 - [GCP Workflow](#)




5.7.2 How do I colorize a Point Cloud?

5.7.2.1 Step 1: Add scan data & Video

1. Open Emesent Aura. Ensuring you have an active **Colorization** license.
2. In the **Process** tab, click **Process Scan+**.
3. In the **Configure New Scan Job** panel, select the **Colorize** workflow.
4. Select **Add Dataset**.




In the dialog box that displays, browse for the folder that contains the point cloud to be colorized. Ensure the scan has been processed and the **.mp4** file or **.360** file is in the same directory. If the video file is detected, it will appear in the **Video file(s)** column (multiple video files will appear if detected depending on the scan duration).






- If there are multiple output folders in the selected scan folder, click the arrow beside the output folder then select from the list.



In addition, in the **Scan File** column, the non-georeferenced output is selected by default. If you want to colorize a georeferenced point cloud, click the arrow beside the scan file then select the file labelled **Scan Processed with Landmarks**.




- Once you have selected the point cloud to colorize, click **Save**.




5.7.2.2 Step 2: Configure Colorization scan job

1. In the **Location** field, enter the preferred name for the output folder. Emesent Aura will create this folder, which stores all the processed results and data, as a child directory within the raw point cloud folder.



2. Select the processing profile to use. Refer to the [Processing Profiles](#) section for more information about which profiles to use and how to create a custom profile.



3. Define colorization settings - refer to the [Creating a Custom Mask](#) section for instructions on creating your own image mask.




5.7.2.3 Step 3: Start processing

1. Click **Start** to begin processing. The panel will show a progress bar showing how far along you are in your processing job. In addition to the progress bar, the elapsed time of the processing job is shown to the right.



2. When prompted, click **Review Frames**.



3. In the file explorer window, manually delete any unwanted frames from your video.
4. Once the unwanted frames are removed, return to Emesent Aura and click **Resume**.




If a failure occurs during processing, the **Retry** buttons becomes available. Click this button to attempt to process the current job from the last successful stage.



5.7.2.4 Step 4: View your final output


1. Once processing has been completed, click **Open folder** to view the output folder or **View** to display your colored point cloud in the Viewport.
2. Click **Close** to remove the scan information from the processing space.
3. The image frames used during colorization can be exported with the colored point cloud. You can find them in the **Intermediate files > frame_extraction > frames** folder. This folder also contains 3 CSV files with pose information in formats compatible with export to Pointerra, Cintoo, Bentley, and Prevu3D.






5.7.3 How do I colorize a Merged Point Cloud?

Colorizing a Merged dataset involves Merging the datasets first, then colorizing each individual scan as a separate Colorization processing job as illustrated in the diagram below.




Below are the steps to colorize a Merged dataset:


1. **Merge** the dataset by following the *Merge Workflow* before starting colorization.
2. **Select** the *Colorize* workflow in the Processing Tray.
3. **Add** the scan folder that contains the merged dataset output.
4. **Set** the merge output folder as your scan folder.



5. **Select** the first scan file to colorize.



6. **Select** the video files that correspond to the selected scan file.



7. **Save** the configuration.
8. **Adjust** processing settings as required by following the *Colorization Workflow Guide*.
9. **Start** processing.
10. **Repeat** steps 5–9 for each additional scan file, selecting the appropriate scan and video files for each.

5.8 Extract 360 Images Workflow

The plug-and-play 360-degree camera accessory for Hovermap, combined with seamless processing in Aura, enables the easy capture, registration, and export of 360 panoramic images.

Please refer to the Knowledge Base asset: [360 Panoramic Image Guide](#) (includes video) for instructions.



5.9 Moving Object Filtering

Identifying moving objects within a point cloud is done by estimating statistical scores for points based on their temporal and spatial relationship to their neighborhood. These scores provide a quantitative measure of the likelihood that a point belongs to a moving object, enabling the Moving Object filter to differentiate between dynamic and static elements in the point cloud.

This feature can be applied to your point cloud as a cleaning filter or from the Processing Settings as part of Emesent Aura's processing workflow.

5.9.1 Using the Moving Object Filter


- Load your point cloud using any of the following options:
 - In the top-left menu, click the **Project Menu** icon then select **Open** from the popup menu.
 - Drag and drop your file directly into the **Viewport**.
 - Go to the **Visualize** tab then click **Add** next to the **Point Clouds** section.
- From the Main Toolbar, click the **Cleaning Filters** icon then select **Moving object filter**.




- In the **Moving Object Filter** dialog box, configure the following parameters as required.
 - Motion level:** Detects movement over 5 second intervals. The higher the value, the lesser moving points are selected.



- Distance:** The maximum distance for recovering fixed points. The higher the value, the more points are retained. A value of 1 to 2 cm is recommended for most scans.




- Under **Point outlying**, choose whether the outlying points will be deleted or just selected. If you choose **Select**, the selected points will show in sepia/gray color.



i Once the points are selected, running the filter again will require the points to be cleared by pressing the **ESC** key. The algorithm only takes into account the whole cloud if no points are selected.





- Once satisfied with the selection, press the **DELETE** key on your keyboard to remove the points.



5.9.2 Applying Motion Filtering from Processing Settings

The filter can also be accessed by enabling **Motion filtering** from the **General** tab in **Processing Settings**. The filter will default to settings based on the profile and detected hardware in the raw scan directory.



 • The filter is disabled by default to avoid accidentally removing some important features with default thresholds including GCP disks if they are not scanned well.

• An aggressive setting may lead to 'holes' on object surfaces in the resulting point cloud.




5.10 Surface Noise Reduction

5.10.1 What is Surface Noise Reduction?


Surface Noise Reduction is a cleaning filter in Aura that smooths point cloud surfaces by reducing random noise. It can be applied during processing or after the point cloud has been generated in the Visualisation view.

The filter works by analysing small groups of nearby points and fitting a smooth surface through them. This removes roughness and irregular noise while preserving important geometric detail. An optional setting is available to limit corner rounding when sharp corners need to be maintained.

The image below shows the effect of Surface Noise Reduction. White points represent the original data with the filter disabled, and red points show the result with the filter enabled. This highlights how the filter removes small irregularities and produces a smoother, cleaner output while preserving the underlying structure.



Without Surface Noise Reduction



With Surface Noise Reduction



Using Surface Noise Reduction produces cleaner and easier to interpret point clouds. It reduces manual cleanup, supports more accurate measurements and CAD linework, and can improve colorization results when used before the colorization step.



Performance depends on point density. Dense indoor scans usually work best with the Low setting, while outdoor or lower density scans may benefit from Medium or High. The filter does not affect accuracy except at very sharp corners, which can be protected with the corner rounding option.

When merging datasets, it is best to apply Surface Noise Reduction after the merge as filtering applied to individual scans pre-merge is not carried through to the post-merge output. In GCP workflows, it is applied both before and after GCP correction.




5.10.2 How to apply Surface Noise Reduction

Surface Noise Reduction can be applied either during processing or after the point cloud has been generated. Applying it during processing saves time by producing a smoother result straight away, while applying it after processing gives you more control and lets you preview the effect before committing to changes. The steps below outline both methods so you can choose the approach that best suits your workflow.

5.10.2.1 Option 1: Apply during processing

Surface Noise Reduction is enabled by default for non-mining scan environments, with **Low** set as the default level. You can adjust this in the processing settings before running your scan.

1. Load your scan using the standard [processing workflow](#)
2. Open Processing Settings
3. Scroll to the Surface Noise Reduction section




4. Choose the level of smoothing you want to apply
 - (see the [Processing Settings](#) for guidance on Low, Medium and High options)
5. (optional) Use Limit corner rounding to keep corners sharp. This can add more noise at corners.
6. Complete standard processing workflow and review results.




5.10.2.2 Option 2: Apply after processing


1. Load a processed point cloud in the Visualisation view
2. Open the Filtering tools
3. Select Surface Noise Reduction



4. Choose the smoothing level you want to apply
 - (see the [Processing Settings](#) for guidance on Low, Medium and High options)



5. Wait for filtering to complete and review the results






5.11 Creating a Custom Mask

When processing a dataset with 360 video for image extraction or colorization, one of the essential steps is applying a mask to the extracted frames. This is because there may be areas in the frame that you do not want to show. Emesent Aura comes with several pre-defined masks that you can use for this purpose but you can also create your custom mask in case none are suitable for your dataset.

To create a custom mask

The following process is demonstrated using GIMP (a freely downloadable editing software). However, you can utilize any third-party image editing software, as the techniques discussed here are applicable across various platforms.


1. Run an **Extract 360 images** workflow with **Image masking** turned off.




i If you have a large video, running image extraction once on a small subset of data is recommended. You can achieve this by setting a high **Frame Extract Interval** (e.g. **Distance: 20** and **Angle: 90**) or specifying a low **Video time end** setting (e.g. **10 seconds**). For Aura 1.5 and earlier versions, you can also use a **Frame Interval** of **250**.



2. Navigate to the extracted frames folder once the frame extraction process is completed.
3. Select a frame you want to create a mask for and open it in GIMP.




4. Adjust the display to ensure the image fits your screen properly.






5. Start with an existing mask instead of creating one from scratch. Open the folder containing the predefined masks by navigating to **Program Files > Aura > Aura> Plugins > EmtProcessWorkflows > Content > ProcessWorkflows > ImageMasks**.
6. Select a suitable mask from either the **colourise** or **FrameExtract** folder then drag this mask onto your current image in GIMP. It will appear as a new layer.






- 7. Use the **Fuzzy Select Tool** (aka **Magic Wand**) and click on the black area of the mask layer to select it.



- 8. In the Layer panel on the right, every layer in the image appears as a thumbnail. The upper layer in the list is the first one visible. Click the **Eye** icon before the mask layer to hide the mask.






Notice that the selected mask area is visible on top of the image.



- Use the **Free Select Tool** to add or refine areas to the mask as needed. Press the **Enter** key to add the area to the current selection.




i Make sure the **Mode** is set to **Add to the current selection**. You can do this by clicking on the second mode icon or pressing the **Shift** key while selecting.

- Keep the frames folder handy and add more frames if necessary. Review each added frame, adjusting the mask to ensure proper coverage, especially around challenging areas like hands or cables.



11. Ensure that the active background color is set to black.



12. Once satisfied with the mask, go to the Layer panel and select the base layer containing the extracted image.






13. Press **Delete** on your keyboard.






- 14. Go to **Select > Invert** then press **Delete** again. The entire image is now black.




- 15. Click the **Bucket Fill Tool**. Ensure the active foreground color is white.






- Click the top area to fill it with the active foreground color (white).



- Go to **File > Export As**. Save the mask in PNG format to avoid the lossy compression issues associated with JPG files.






18. Click **Export**.

i If using Emesent Aura version 1.5 or earlier, change the pixel format to **8bpc RGB**.

19. Close GIMP and return to the Emesent Aura.


To add the custom mask in Aura

1. Run a **Colorize** or **Extract 360 images** workflow again.
2. Click **Processing Settings**.
3. In the **Colorize** or **Extract 360 images** tab, enable **Image masking**.






- In **Mask template**, click the + icon.
- Enter a name for the custom mask, click **Create** then browse for the newly created mask.



- Click **Save** to finish adding the custom mask to Emesent Aura.





5.12 Reprojection

Reprojection in Emesent Aura is an automated workflow that allows for RTK scans to be processed with the correct coordinates by simply selecting the target coordinate reference system (horizontal) and converting from ellipsoidal height to orthometric height using a GEOID model (vertical). This can be done via **Processing Settings** when processing raw data or **Export reprojection** from the **Project menu** if exporting a georeferenced point cloud.


The following video shows how to use Emesent Aura to easily reproject your raw RTK scan during processing and reproject your older scan during export.

5.12.1 Configure a scan for reprojection


Processing raw RTK scan data in Aura allows you to generate an accurately georeferenced point cloud while applying the correct coordinate reference systems for your project. During setup, you can specify the base CRS used during capture, apply reprojection to a new horizontal and vertical CRS, and incorporate custom geoid models where required. The steps below guide you through configuring and processing an RTK dataset from start to finish.

5.12.1.1 Step 1: Create a New Processing Job

1. Open Emesent Aura and go to the **Process** tab.
2. Select **+ Process Scan** to create a new scan job.
3. In the **Configure New Scan Job** panel, select the **Slam/RTK** workflow.
4. Click **Add Dataset**, browse to the folder containing the scan data.



- When Aura detects RTK data in the dataset, toggle on **Use RTK data**.



5.12.1.2 Step 2: Configure Output Location

- In the **Location** field, enter a name for the output folder.
- Aura creates a subfolder with this name, which stores all processed outputs.




5.12.1.3 Step 3: Set Georeferencing Options

- Click **Processing Settings**.
- Under **Georeferencing** in the **General** tab, select the **RTK device** and **GNSS receiver** used during data capture.




For optimal results, ensure that the **Georeferencing mode** and **GNSS receiver type** match the hardware used during data collection. While the resulting point cloud remains usable, the accuracy may be affected.




5.12.1.4 Step 4: Define the Base CRS

1. Under **Base coordinate reference system**, select the CRS in which the data was originally collected.



- Alternatively, toggle on **Custom base coordinate reference system** to manually enter a PROJ string describing the geodetic CRS.



5.12.1.5 Step 5: Enable and Configure Reprojection

- Toggle on **Reprojection** to enable CRS transformation for the processed output.



Reprojection

If you intend to merge this data please note reprojected point clouds are not suitable for alignment in merge. Consider reprojecting all point clouds as part of the merge workflow instead.

- 2. From the **Horizontal** dropdown, select a predefined CRS for horizontal reprojection.

Reprojection

If you intend to merge this data please note reprojected point clouds are not suitable for alignment in merge. Consider reprojecting all point clouds as part of the merge workflow instead.

Target coordinate reference system ?

Horizontal **EPSG:10601 - WGS 84 / GLANCE Oceania**

Vertical

Custom

Please use the


Recently used

- EPSG:4161 - Pampa del Castillo
- EPSG:4179 - Pulkovo 1942(58)
- EPSG:4674 - SIRGAS 2000
- EPSG:7856 - GDA2020 / MGA zone 56
- EPSG:10601 - WGS 84 / GLANCE Oceania**


Predefined CRS

- EPSG:3819 - HD1909

- 3. Once a Horizontal CRS is selected, the **Vertical** dropdown becomes active. From the **Vertical** dropdown, select a predefined vertical CRS, or click **Import geoid file** to upload a your own geoid file (GTX or TIF).



- Alternatively, toggle on **Custom target coordinate reference system** to manually enter a PROJ string describing the target CRS.



5.12.1.6 Step 6: Finalise Settings and Start Processing

Click **Save** to apply all configuration settings and return to the **Configure New Scan Job** panel. Start processing the scan, then review the output in the **Visualize** tab once complete.

5.12.2 Reprojecting a processed point cloud


Reprojecting an existing processed point cloud allows you to transform the dataset into a new horizontal and vertical coordinate reference system (CRS) without reprocessing the raw scan data. This is useful for correcting projection metadata, aligning data from multiple sources, or converting ellipsoidal heights to




orthometric heights using standard or custom geoid models. Follow the steps below to reproject a processed point cloud in Aura.

5.12.2.1 Step 1: Open Aura Export Reprojection

1. Open Emesent Aura and go to the **Visualize** tab.
2. Load the processed point cloud or trajectory you want to reproject.




3. Click the **Project** menu icon, then select **Export reprojection**.



5.12.2.2 Step 2: Review or Edit the Source CRS

Aura automatically detects the CRS, but editing may be necessary if the CRS is incorrect or the dataset includes multiple sources. To edit the source CRS.

1. In the **Export Reprojection** dialog box, click **Edit Source CRS**.



2. Refer to the **Context Panel** on the right to view the projection information of the current point cloud.



Point cloud properties ▼

Points: 18 695 443

Georeferenced properties ^

[VIEW RTK ACCURACY REPORT](#)

Projection Information 📄

CRS:	GDA2020 / MGA zone 56
Proj:	Transverse Mercator
Ellipsoid:	GRS 1980
Datum:	Geocentric Datum of Australia 2020
Units:	Meter

Coordinates

Latitude:	0.000000
Longitude:	153.000000

Transformations

Scaling:	0.999600
False northing:	10000000.000000
False easting:	500000.000000

Origin offset (m) ^

x: 0.000	y: 0.000	z: 0.000
----------	----------	----------

Bounding box size (m) ^

x: 233.239	y: 228.858	z: 65.672
------------	------------	-----------

4. Alternatively, toggle on **Custom target coordinate reference system** to manually enter a PROJ string describing the desired CRS.



EXPORT REPROJECTION

Select the source projection used when capturing the dataset.

Source coordinate reference system ?

Horizontal ▼

EPSG:7856 - GDA2020 / MGA zone 56

Vertical ▼

EPSG:5711 - AHD height

Custom source coordinate reference system

Please use the entire proj string to reproject your data.

EPSG code detected. Use as `EPSG:7856 - GDA2020 / MGA zone 56 + EPSG:5711 - AHD height`

```

COMPD_CS["GDA2020 / MGA zone 56 + AHD height",
  PROJCS["GDA2020 / MGA zone 56",
    GEOGCS["GDA2020",
      DATUM["Geocentric_Datum_of_Australia_2020",
        SPHEROID["GRS 1980",6378137,298.257222101,
          AUTHORITY["EPSG","7019"]],
        AUTHORITY["EPSG","1168"]],
      PRIMEM["Greenwich",0,


```

✓

NEXT
CLOSE

5.12.2.3 Step 3: Select the Target CRS

1. From the Horizontal dropdown, select a predefined coordinate reference system (CRS) from the list.
2. Once the Horizontal CRS is selected, the **Vertical CRS** dropdown becomes active.
3. From the **Vertical** dropdown, select a predefined vertical CRS, or click **Import geoid file** to upload a custom geoid (GTX or TIF).



- Alternatively, toggle on **Custom target coordinate reference system** to manually enter a PROJ string describing the target CRS.



EXPORT REPROJECTION

Reproject the data into the desired target coordinate reference system (CRS) for the final output. Changing the source CRS is optional.

Source coordinate reference system *(optional)* ?

[EDIT SOURCE CRS](#)

* Target coordinate reference system ?

Horizontal

Vertical

Custom target coordinate reference system

Please use the entire proj string to reproject your data.

 Reproject trajectory
 Replace loaded point clouds with exported reprojection

[SAVE](#) [CLOSE](#)

5.12.2.4 Step 4: Apply Optional Reprojection Settings

1. Enable **Reproject trajectory** to apply reprojection to the associated trajectory data.
2. Enable **Replace loaded point cloud with exported reprojection** to automatically load the newly reprojected point cloud into the Visualize tab.



EXPORT REPROJECTION

Reproject the data into the desired target coordinate reference system (CRS) for the final output. Changing the source CRS is optional.

Source coordinate reference system *(optional)* ?

[EDIT SOURCE CRS](#)

* Target coordinate reference system ?

Horizontal

Vertical

Custom target coordinate reference system

Reproject trajectory

Replace loaded point clouds with exported reprojection

[SAVE](#) [CLOSE](#)

5.12.2.5 Step 5: Export the Reprojected Point Cloud

1. Click **Save** to export the reprojected point cloud.
2. The results are good saved in the same output folder as the original point cloud.

5.13 Measure Tools


The **Measure Tools** in Aura enable you to interact directly with the point cloud to obtain accurate spatial information. They are valuable for inspections, validation, and for communicating key dimensions directly within the 3D environment.

Aura includes three measurement tools


- **Measure Point** to record the coordinates of a single point.
- **Measure Line** to calculate the distance between two points.
- **Measure Angle** to determine the angle formed by three points.



The Measure Tools are accessed from the **Main Toolbar**, located at the top of the Aura interface.



When a **measurement tool** is active, Aura displays the **full resolution** of points around the **cursor**, enabling accurate point selection. To maintain a **performant user experience**, points further from the cursor are not displayed. The size of the loaded area adjusts automatically based on the **camera position** and the current **point budget** setting.



5.13.1 Measurement Tools

Measure Point




The **Measure Point** function records the location of a single point in the point cloud. When selected, Aura displays an **information label** showing the point name and its **X, Y, and Z coordinates** in the project's coordinate reference system.



Measure Line

The **Measure Line** function calculates the distance between two points.


- Select a starting point (**A**) and then an ending point (**B**).
- Aura displays labelled markers at each point and generates an **information label** showing the measured distance and the assigned measurement name.



Measure Angle

The **Measure Angle** function determines the angle formed by three points.



- Select the first point to define the start of the first line segment.
- Select a second point to define the **vertex** (the central point of the angle).
- Select a third point to define the end of the second line segment.
- Aura displays labelled markers for each point and generates an **information label** showing the calculated angle at the vertex and the assigned measurement name.




5.13.2 Managing Measurements

All measurements appear in the **Visualize tab** and are grouped by type: **Point, Line, or Angle**. They are named **sequentially** within each type based on the order of creation.

i Deleting a measurement does not reset the sequence. For example, if *Point 2* is deleted, the next point created will still be named *Point 3*.

From the Visualize tab, you can also control measurement visibility. Use the  **view icon** to hide a measurement, or the  **remove icon** to delete it permanently.



5.13.3 Measurement Details

The **Measurement Details** panel provides additional information about a selected measurement. It displays the point's **X, Y, and Z coordinates** along with contextual values, depending on the type of measurement:



Point

- **X, Y, Z coordinates** – the location of the selected point.


Line

- **Line length** – the true 3D distance between two measured points.
- **Horizontal** – the distance between the points in the horizontal plane (X-Y), ignoring elevation.
- **Vertical** – the difference in elevation (Z) between the points, ignoring horizontal distance.
- **Coordinates** – the X, Y, and Z values of both endpoints.

Angle

- **Magnitude** – the measured angle between three selected points.
- **Coordinates** – the X, Y, and Z values of all three points.

The **Measurement Details** panel can be viewed by selecting a measurement in the **Visualize** tab. The details then appear in the **Properties** panel on the right-hand side.






Point	Line	Angle
<p>Measurement detail</p> <p>Location</p> <p>X -4.39 Y -0.39 Z 1.20</p>	<p>Measurement detail</p> <p>Length: 2.90</p> <p>Horizontal: 2.90 Vertical: 0.10</p> <p>Coordinates</p> <p>1 X -4.366 Y -0.425 Z 0.124</p> <p>2 X -1.467 Y -0.347 Z 0.226</p>	<p>Measurement detail</p> <p>Magnitude: 61.38</p> <p>Coordinates</p> <p>1 X -4.164 Y -2.602 Z -0.048</p> <p>2 X -3.076 Y -0.861 Z -0.017</p> <p>3 X -2.146 Y -2.514 Z -0.056</p>

5.13.4 Renaming Measurements


Measurements can be renamed for easier organisation. Select a measurement in the **Visualize** tab and edit its name in the **Properties** panel on the right-hand side. Renamed **Point** measurements will use this updated name in the **CSV export**.



5.13.5 Export Points

Points can be exported as a CSV file containing **ID, X (Easting), Y (Northing), and Z (Elevation in metres)**. This option is available from the **File** menu in Aura.

Only **georeferenced** scans can export point data. If the scan is not georeferenced, Aura will generate an empty CSV file.



5.14 Aura scan environments

Aura Scan Environments determine the default processing settings applied during processing, such as Surface Noise Reduction and SLAM time window values. Select the environment that most closely aligns with your scan for optimized processing settings and output results.

Aura prompts you to choose a Scan Environment when you add a dataset for processing. Once selected, the environment is saved in the scan folder and will be automatically used the next time you process that scan. You can change the environment at any time through the Processing Options.



SCAN ENVIRONMENT

*Select the environment that most closely aligns with your scan for optimized processing settings and output results:

Building and infrastructure

- Building interior
- Building exterior
- Bridge
- Road
- Tunnel / Sewer / Culvert

Facility

- Facility
- Forestry / Vegetation
- Greenfield

Mining

- Surface mining
- Access & transport drives
- Production voids
- Vertical infrastructure
- Waterway / Coastline

5.14.1 How Aura uses Scan Environments

Each Scan Environment applies a predefined set of default processing parameters. These defaults ensure that Surface Noise Reduction and SLAM time window settings are appropriate for the environment captured.



5.14.2 Default Processing Behaviour by Environment

Scan Environment	Surface Noise Reduction	SLAM Time Window	SLAM Window Shift
Building and Infrastructure			
Building interior	ON	10	0.5
Building exterior	ON	10	0.5
Bridge	ON	10	0.5
Road	ON	10	0.5
Tunnel / Sewer / Culvert	ON	10	0.5
Mining			
Surface mining	OFF	5	1
Access & transport drives	OFF	5	1
Production voids	OFF	5	1
Vertical infrastructure	OFF	10	0.5
Other			
Facility	ON	10	0.5
Forestry / Vegetation	ON	10	0.5
Waterway / Coastline	ON	10	0.5
Greenfield	ON	10	0.5



6. Glossary

6.1 General Terms

Term	Definition
Constellation	A collection of targets and landmarks, and the way that they sit in relation to each other. A constellation is <i>associated</i> with the point cloud, but is separate from it.
EDL	Eye dome lighting. Improves depth perception by shading the outline of points, accentuating the shape of each object.
File formats supported	<ul style="list-style-type: none"> • LAS: Contains the point cloud. Industry-standard file format for LiDAR data. • LAZ: A compressed LAS file. • E57: A compact file format used for point cloud storage. Only E57 files generated by Emesent Aura are supported. • SLAZ: A Streaming LAZ file. Instead of loading the entire point cloud, Emesent Aura only streams images of the portion of the point cloud that you are looking at, “discarding” the rest. This is an optimized way of looking at scans, which means a faster loading time than the usual LAZ datasets. • XYZ: A widely-supported point cloud format. In the context of Emesent Aura, XYZ files appear in the Entity panel as a trajectory point cloud, showing Hovermap’s path. • PLY: Standard mesh file format. • YAML: A configuration file attached to a LAS file. In the context of Emesent Aura, a YAML file is the constellation of GCPs. The file superimposes targets over your point cloud. The default name is <i>constellation.yaml</i>.
GCPs	Ground control points. GCPs are points with known geographical coordinates.
Intensity	Measures how much of the emitted laser signal is returned. It is based mostly on the reflectivity of the object struck by the laser, but can also be affected other factors, such as the scan angle, surface composition, roughness and moisture content.



Term	Definition
Landmark	The GPS coordinates entered in the CSV file. These are referred to as landmarks in Emesent Aura.
Mesh	A 3D model consisting of vertices, faces and edges.
Point cloud	A collection of individual points plotted in a 3D space.
Scalar field	<p>Scalar fields give you a single, measurable value for each point in your point cloud. Because each value is associated with one point, it is possible to show the point cloud using a color gradient that is based on these measurable values.</p> <p>These values also allow you to apply filters to your point cloud.</p>
SLAM	Simultaneous localization and mapping. SLAM technology runs in real-time to allow Hovermap ST to create a map of its environment, while at the same time working out its position, orientation, and speed within that environment.
Target	The reflective disc aligned to a GPS coordinate.
Transform	Records the orientation differences between point clouds after you have done a manual alignment. Emesent Aura works in the background to record this automatically. The transform then tells the processing job what to do to align the scans properly.
Translate	To move or shift the point cloud along an axis.
Units	All units in Emesent Aura are in meters.
Licence	A licence grants permission to use Aura's processing features. Each licence includes one or more modules , which enable specific functionality such as SLAM processing or RTK corrections.
Seat	A seat is a single unit of access to Aura's processing capabilities. Seats can be shared by multiple users within your organisation but can only be used by one user at a time.
Module	Modules are specific functional components within Aura. Licences may include access to one or more of the following modules:



6.2 Aura Modules

Module	Description
SLAM	Enables SLAM (Simultaneous Localization and Mapping) processing.
RTK	Allows integration of RTK GNSS data for improved georeferencing.
GCP	Enables georeferencing using Ground Control Points.
Merge	Allows merging of multiple scans into a single aligned point cloud.
Colorize	Adds colour information to point clouds using captured imagery.
Extract 360 Images	Extracts 360° images along the trajectory path.
Convergence Monitoring	Enables tools for assessing alignment accuracy across multiple scans.



7. Support

Emesent offers multiple support pathways to help you troubleshoot, learn, and get assistance quickly. Use the options below to access the resources that best meet your needs.

7.1 Chat with Emi

- Get quick answers, guided troubleshooting, and help finding the right resources through our interactive AI agent.

7.2 Knowledge Base

- Access user guides, tutorials, troubleshooting articles, and other essential product resources.

7.3 Emesent Academy

- Take guided training courses to build knowledge and improve your skills with Emesent products.

7.4 Submit a Support Request

- Log technical issues, incidents, or feature suggestions so our team can assist you promptly.



When submitting a request, provide as much detail as possible to assist the support team in resolving the issue efficiently.



PREPARED BY:
EMESENT PTY LTD
LEVEL G, BUILDING 4, KINGS ROW OFFICE PARK
40-52 MCDOUGALL ST, MILTON, QLD, 4064 AUSTRALIA

EMAIL: CUSTOMER-SUCCESS@EMESENT.IO
PHONE: +61 7 3548 9494